
SERVICE MANUAL



AEP Model

KV-C2521D Chassis No. SCC-D51E-A

Chassis No. SCC-D51D-A

AE-1B CHASSIS

Note: The service manual for RM-689 has been issued separately.

MODELS OF TH	IE SAME SERIES
KV-C2521D/C2531D	
KV-X2531D	
KV-X2131D	

SPECIFICATIONS

Television system B/G/H

Color system

PAL, SECAM, NTSC3.58, NTSC4.43

Channel coverage VHF: E2-E12

UHF: E21-E69

CABLE: S1-S41

Picture tube

Trinitron tube

Approx. 63.5 cm (25 inches)

(Approx. 59 cm picture measured diagonally

110-degree deflection

Inputs

🖰 1 21-pin connector :

CENELEC standard including RGB input.

→ 2 21-pin connector: including S video input

3 Video, Audio: phono jack.

Outputs

21-pin connector: CENELEC standard Headphones jack: stereo minijack External speaker terminals: 2-pin DIN Audio output jacks: phono jack (output

dependent upon TV settings)

MICROFILM

15 W + 15 W (KV-C2521D) Sound output

30 W + 30 W

Power consumption 96 Wh (KV-C2521D)

101 Wh

Dimensions

Approx. 769x492x478 mm (w/h/d)

Weight

Approx. 37.0 kg (KV-C2521D)

38.0 Kg

RM-689 Remote Commander (1)


Supplied accessories IEC designation R6 batteries (2)


Design and specifications are subject to change

without notice.

TRINITRON® COLOR TV

21 pin connector (+ 1, - 2)





Pin No	1	2	Signal	Signal level
1	0	0	Audio output B (right)	Standard level: 0.5Vrms Output impedance: Less than 1kohm*
2	0	0	Audio input B (right)	Standard level: 0.5Vrms Input impedance: More than 10kohms*
3	0	0	Audio output A (left)	Standard level: 0.5Vrms Output impedance: Less than lkohm*
4	0	0	Ground (audio)	
5	0	0	Ground (blue)	
6	0	0	Audio input A (left)	Standard level: 0.5Vrms Input impedance: More than 10kohms*
7	0	•	Blue input	0.7V±3dB, 75ohms, positive
8	0	0	Function select (AV control)	High state (9.5-12 V): Part mode Low state (0-2 V): TV mode Input impedance: More than 10kohms Input capacitance: Less than 2 nF
9	0	0	Ground (green)	
10	0	0	Open	
11	0	•	Green	Green signal: 0.7V±3dB, 75ohms, positve
12	0	0	Open	
13	0	0	Ground (red)	
14	0	0	Ground (blanking)	
	0	-	Red input	0.7V±3dB. 75ohms, positive
15	_	0	(S signal) croma input	0.3V±3dB, 75ohms, positive
16	0	•	Blanking input (Ys signal)	High state (1-3 V) Low state (0-0.4 V) Input impedance : 75ohmes
17	0	0	Ground (video output)	
18	0	0	Ground (video input)	
19	0	0	Video output	1V±3dB, 75ohms, positive Sync: 0.3V (-3, +10dB)
25	0	-	Video input	1 V±3dB. 75ohms, positive Sync: 0.3V (-3, +10dB)
20	-	0	Video Input/Y (S signal)	1 V±3dB, 75ohms, positive Sync: 0.3V (-3, +10dB)
21	0	0	Common ground (plug, s	shield)

O connected

unconnected (open)

* at 20 Hz-20 kHz

WARNING !!

AN ISOLATION TRANSFORMER SHOULD BE USED DURING ANY SERVICE TO AVOID POSSIBLE SHOCK HAZARD, BECAUSE OF LIVE CHASSIS.

THE CHASSIS OF THIS RECEIVER IS DIRECTLY CONNECTED TO THE AC POWER LINE.

SAFETY-RELATED COMPONENT WARNING!


COMPONENTS IDENTIFIED BY SHADING AND MARK

ON THE SCHEMATIC DIAGRAMS, EXPLODED
VIEWS AND IN THE PARTS LIST ARE CRITICAL TO
SAFE OPERATION. REPLACE THESE COMPONENTS
WITH SONY PARTS WHOSE PART NUMBERS APPEAR
AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS
PUBLISHED BY SONY.

TABLE OF CONTENTS

Section	<u>Title</u> <u>Page</u>	<u>Secti</u>	on	\underline{Title}	Page
1. (GENERAL	4.	CIRCUIT ADJUSTMI	ENTS	
1-1.	Function of Controls4				
1-2.	To Preset Channels6	4-1.	A Board Adjustmen	ıt	16
1-3.	Viewing Teletext7	4-2.	B Board Adjustmen	t	16
1-4.	Operating Other Equipment7	4-3.	D Board Adjustmen	t	17
1-5.	Connecting Other Equipment8	4-4.	J1 Board Adjustmer	nt	17
		4-5.	V Board Adjustmen	it	18
2.	DISASSEMBLY	4-6.	Secondary Adjustme	ent	18
2-1.	Rcar Cover Removal9	5.	DIAGRAMS		
2-2.	Chassis Assembly Removal9				
2-3.	A and J1 Boards Removal9	5-1.	Block Diagram	• • • • • • • • • • • • • • • • • • • •	19
2-4.	B and V Boards Removal10	5-2.	Circuit Boards Loca	ntion	23
2-5.	Service Position	5-3.	Schematic Diagrams	s and Printed Wiring	Boards24
2-6.	Picture Tube Remval11	5-4.	Semiconductors	• • • • • • • • • • • • • • • • • • • •	49
3. 9	SET-UP ADJSTMENTS	6.	EXPLODED VIEWS		
3-1.	Beam Landing12	6-1.	Chassis	• • • • • • • • • • • • • • • • • • • •	50
3-2.	Convergence	6-2.	Picture Tube		51
3-3.	Focus14				
3-4	White Balance	7.	ELECTRICAL PARTS	LIST	52

1-1. FUNCTION OF CONTOROLS



ON THE SET

(A) Power Switch (D)
Use it to switch the set on and off. When you switch the set on, the programme number of the station tuned in will be indicated in the on-screen display (A) for some seconds. In case of short breaks of operation, you can switch the set on and off using the Remote Commander (See »CONTROLS ON THE REMOTE COMMANDER«).

(See »CONTROLS ON THE REMOTE COMMANDER».

© the Standby/Reponse indicator
This indicator lights up when the TV set is in standby mode and it flashes each time the set receives signals from the Remote Commander.

② Stereo A/B indicators ○
During bilingual programmes one of the two indicators lights up, depending upon the selected channel A or B. When stereo programmes are broadcast both indicators light up. (See "CONTROLS ON THE REMOTE COM-MANDER").

Jacks and control panel (front of set)

The jacks and the control panel are situated behind a cover. Please press the arrow marking on the cover to open it.

E : Headphones jack (stereo minijack)

Connect only stereo headphones.

F @ Input jacks (KV-C2531D only)

Video input jack (phono jack) **⊕·3** (yellow) Audio input jacks (phono jacks) ⊕ (red and white).

 Mode select button
 Use this button to select either the channel select mode, volume adjustment Δ or the Φ input mode

(H) Adjustment buttons +/Select at first the item to be adjusted using the Mode select
button (G) (P: channel select mode), A (volume) or (E) (input mode), then adjust the item by pressing the + or

You can also use these buttons to reset the picture and sound adjustments to the factory-set levels. For this purpose press both buttons simultanteously.

When you repeatedly press button # 1.2 on the Remote Commander, the following information will be indicated on the screen in turn:

Picture and sound adjustment items:
 Contrast, Colour, Conghtness, Fass, Feble or Contrast, Colour, Conghtness, Colour, Conghtness, Colour, Co

When you press button ⊕ io on the Remote Commander, the following information will be indicated on the screen:

(K) TV-System: I (normal UK broadcast system)

(L) Channel number

M Programme number or input mode;

01, 0, 0-2, 6-2, 0-3;

N Indication of the station name

 $\bigcirc \hspace{-0.5cm} \textbf{AV output indication; 1} \ \ominus , 2 \ \ominus , 3 \ \ominus \text{ or TV} \ \ominus \text{ (see "CONTROLS ON THE REMOTE COMMANDER")}.$

Connectors on the rear


(P) Euro-AV-connector 21-pin (→ 2/ ⊕ 2 For connecting a VTR, 8 mm video camera recorder, a video

disc player or in general devices with an S-Video-output.

Q Euro-AV-connector 21-pin [™]-1 For connecting a VTR, a computer etc. with RGB output.

(B) Audio-output-jacks (phono jacks) \ominus -For connecting audio equipment, e.g. an amplifier, so that the sound will be output at the audio equipment. In this case the volume is adjustable on the TV set.

S Aerial terminal T



ON THE REMOTE COMMANDER

On the set there is a Remote Control detector (B), which receives the signals of the Remote Commander

◆ Preset-button Used for selecting the Preset mode. See »TO PRESET CHANNELS«.

2

(##) Tuning +/- buttons
a) Preset mode: Used for tuning in stations in the Automatic Station Search: See "TO PRESET CHAN-

TV-mode Used for fine-tuning a station Res ADDI-TIONAL FUNCTIONS«

ŝ

Coo button (Clear) 8

Used for clearing programme positions, so that the position will be skipped when the PROGR +/− buttons are pressed. See *TO PRESET CHANNELS*.

♦ Store button: Used for storing channels. See "TO PRESET CHANNELS."

4

★ TV-system-select-button This button has no function.

9

Video selector and video operation buttons

9

^

Used for operating Sony video equipment. For details see "OPERATING OTHER EQUIPMENT".

By pressing this button the sound of the set will be switched off and by pressing it once more the sound channel numbers (in the preset mode).
b) If the set is in the standby mode, press one of the After pressing the output select button G+ the Used to select programme positions or to input number buttons to switch it on. **Number buttons** will be restored. a O

00

Ø

In case of two digit numbers, press first this button and then the two respective number buttons B.

buttons 1-2 can be used to select the different output

Button for On-screen display 0

tuned-in will be indicated on the screen. The indications will disappear after some seconds with the exception of the programme number and label, which By pressing this button, information about the station will stay on the screen until the button is pressed once

Time button (

In TV-mode: If teletext service is broadcast on the selected channel, press this button to display the current time on the screen and once again to make it

+/- Buttons for picture and sound adjustments 12

The picture and sound adjustments are stored as standard values. You have, however, the possibility to change them to your individual liking. Press the button repeatedly until the required item is indicated in the onscreed nisplay. @ confrast, @ colour, brightness, \(\tilde{\text{table}}\) hue (only for NTSC colour system), \(\tilde{\text{Description}}\) basis, \(\text{\$\psi\$ treble or \text{\$\te b) Preset-mode: Use these buttons to name a station. See "TO PRESET CHANNELS". the + or - button. a) TV-mode:

→ • ← Reset-button

13

By pressing this button the picture and sound adjustments are reset to the factory-set levels.

© Standby-button

14

Press this button to switch the set into standby-mode. You can switch it on again by pressing the TV-button of or one of the number buttons of I or return to the telefext mode, press of of blabton. There will be a slight delay before the picture is restored.

Note

Use the Standby-button 🖆 only when switching the set off for a short period of time. If the set will not be used for a longer span of time, switch it off by using the Power switch (A)

⊕ Input-Select-Button

input at the various input connectors. With each pressing of the button a different connector is selected. The following indications will appear sequentially: Press this button to select the audio- or video-signals 15

$\bigoplus 1 \rightarrow \overline{\bigcirc} + (RGB) \rightarrow \bigoplus 2 \rightarrow \bigoplus 2 \rightarrow \bigoplus 3$ TV Mode ▲

O TV-Button

16

When pressing this button the set returns from standby, video input- or teletext mode to the TV-mode.

Output-Select-Button

Press this button to select the audio- or video signals to be output at the $\mathbb{C}\mathcal{M}\mathbb{E}$ connector. With each pressing of the button a different output source will be selected. The following indications appear sequentially: 17

10,20,30,TVQ

Teletext operation buttons

By pressing this button the high and low tones will be emphasized. Peres the button again to restore the normal sound. The indications on the screen will be V(0M) or W (0FF). These buttons are used for teletext operation. See "VIEWING TELETEXT". Loudness button

-6

A/B button

Usually the dubbed version is broadcast on channel **A** and the original sound is broadcast on channel **B**. In the video input mode (Euro-AV-connectors) this possibility of selecting channels also exists for stereo To select the audio channel of bilingual programmes 20

C (Channel select) button

21

Use this button for direct channel tuning in the TV-mode. See "ADDITIONAL FUNCTIONS".

This button has no function on this set. 22

⊕ Space sound button
Press this button to obtain special acoustic effects.
Press it again to restore the normal sound. The indications on the screen will be ⊕ (on) or ⊕ (off). 23

PROGR +/- buttons

grammmes up- or downwards.

Preset mode: Use these buttons to scan the available TV-mode: Use these buttons to scan the available prochannels up or downwards. 24

+/- buttons for adjusting the volume 25

Battery compartment (on the rear)

26

Use the buttons on the Remote Commander for presetting. In total there are 60 programme positions at your disposal


There are two different ways of tuning in channels:

I. Direct Channel Tuning


If you know the channel number of a station you can input it

2. Automatic Station Search


The set searches automatically for stations.




1. Direct Channel Tuning
1. Press the Preset button ⇒ □. You are now in the preset mode of the set. The programme number in the on-screen display (M) starts blinking.




2. With the buttons PROGR +/-[2] or the number buttons [8] you can select the programme position. In case of two-digit numbers, press first the button -/-- [3] and then the two



3. Press button C [2] The indication "C" and the channel number start blinking in the display (L). Select the channel number with two digits (e.g. 22) using the number buttons



4. Press the button ♦ ⚠ in order to store the channel and to return to the TV-mode.



If you want to store further channels, repeat the steps 1 to 4.

2. Automatic Station Search

1. Press button riangle 1. You are now in the preset mode of the set. The programme number in the on-screen display (N) starts blinking. **2.** With the PROGR buttons +/-[2] or the number buttons [3] you can select the programme position. In case of two-digit numbers, first press button -/-[3] and then the two number

station search. The search will be interrupted as soon as a station is tuned in. Press the tuning buttons repeatedly until 4. Press one of the tuning buttons 🕶 +/- 2 to start the you find the desired station. **5.** If you have found the desired station, press button \diamondsuit [4]. Now the selected station is stored and you are back in the

If you want to store further stations, repeat the steps 1-5.

Skipping of unused programme positions

programme positions (e.g. without a stored station), when pressing the buttons PROGR +/- [24] on the Remote Using button Co. 3 you have the possibility to skip unused

1. Press button ⇒ 🗓. You are now in the preset mode of the

2. Use the buttons PROGR +/- 21 to select a programme position, which you want to have skipped.

If you want to name a station After presetting the stations you have the possibility to name

3. Press button (1) 12 again. Now the second column starts blinking and you can select the second character. In this way five characters can be selected.

Press button ◊ 4 to store the station name.



Notes

"x" will be displayed on the screen.


button should be pressed within 5 seconds after the first one, otherwise the operation will be cancelled.

ADDITIONAL FUNCTIONS

Direct Channel Tuning in the TV-mode

You have the possibility to tune in channels directly when the set is in the TV-mode without storing these channels. Example: If you tune in channel number 32 and then switch the set off or change the programme position, this channel will be cancelled

1. Press the button C 🔄 . In the display 🕒 the indication "C« will appear 2. Select the channel number with two digits using the number but but so [8] (e.g. for channel 4 press first 0, then 4). The indication on the screen will disappear within some



Manual Fine Tuning

possibility to deactivate the Automatic Fine Tuning, which is If the reception of a channel is not satisfactory, you have the usually in operation during presetting in order to tune in the best possible picture.

Press one of the tuning buttons $\overline{(44)}$ +/- \overline{z} to fine-tune a channel. The Automatic Fine Tuning will be restored when the respective programme position is pressed once again

3. Press button Coo 3

The skipped programme position still appears when you press the number buttons [8] on the Remote commander

them. The selected name will appear in the on-screen display (N).

Press the preset button ⇒ □

2. Press the button 🖲 🔃 The first column of the station name starts blinking. Press either button + or – 🔃 and select the desired character (number or letter, 0-9, A-Z, or

If you press the preset button ⇒ [·] instead of button
 △ the set will return to the TV-mode without storing the

 If you press a wrong programme or a channel number, an channels.

When pressing two number buttons, the second number

VIEWING TELETEXT 1-3.

To view the teletext service, use the Remote Commander The buttons for teletext operation are indicated in green

Select the TV channel for the desired teletext service. If the signal is weak, teletext errors often occur.

2 Press (2) (TEXT/MIX) to display the teletext service.

buttons. If an error is made, complete the three-digit sequence by keying in any digit. Then, re-enter the correct Key in the three digits of the desired page using the number page number.

The requested teletext page is displayed.

fo return to the TV mode, press TV 📧 on the Remote Com-

To receive the teletext service of a different TV channel 1 Press TV 13 to return to the TV mode.

2 Select the desired TV channel.

3 Press (**) (**) (**) (**) (**) The teletext service can be displayed directly from the standby mode by pressing () (| TEXT/MIX).

Note

Buttons not referred to in the text do not operate

To request the index page Press (1) (INDEX).

if the necessary signal is not being broadcast, page 100 is

displayed

To access the next or preceding page Press ऒ (PAGE +) or ऒ (PAGE -).

To superimpose the teletext display on the picture (MIX) Press 등 (의 Wice from the TV mode. Press 등 (의 의 again to return to the TEXT display.

To suppress the teletext display so that the picture is

Press (3) (text clear). This button can be operated from both the text and mix displays.

Press ® (HOLD). The HOLD symbol appears on the screen. To resume normal teletext reception, press ® I Ø (TEXT/MIX). To prevent a teletext page from being updated/changed



To resume normal teletext reception, press (8) (10)

To enlarge the teletext display

Press (a) once to enlarge the upper half of the display; press again again to enlarge the lower half of the display. And press again to return to the normal display. To reveal concealed information such as answers to a quiz Press (3) (REVEAL). Press again to conceal the answers To watch the TV programme while waiting for a requested Request the new page page to be displayed

FASTEXT Operation

FASTEXT Teletext enables you to access pages quickly and conveniently with one key operation. appear at the bottom of the screen. Each coloured prompt Pressing one of these will select the page described by the prompt. relates to the coloured keys on the Remote Commander

2 Press ® to watch the TV programme.

The requested page number and other data appear at the top of the screen. When the requested page has been captured, the page number is displayed in the top left hand corner of the

P101

screen.

To view this page, press (*) (*).

To have a requested page displayed at a pre-determined

1 Request a time coded page (e.g. alarm page).
2 Press @ (TP ON).
" T * * * * " will appear at the bottom of the screen.

3 Enter your request time with the number buttons, using four digits. For example, 07.30:

T0730

To watch the TV programme until the requested time, press (3) (TEXT CL). At the requested time, the page number will be (TEXT CL). At the requested time, the page number will displayed at the bottom of the screen.

To view this page, press **B** / **D**.

To cancel the request, first ensure that the teletext page is displayed, then press **®** (TP OFF).

Selection may also be made by entering the three digit page number in the normal way.

Correct FASTEXT operation relies on the necessary signals being transmitted by the Broadcasting Authorities. It is possible that some Broadcasters will not support this

transmission.

If FASTEXT is not transmitted, the decoder will operate as outlined above.

OPERATING OTHER EQUIPMENT

4.

To view the input picture

Press the ⊕ Is button repeatedly until the desired input signal indication appears on the screen.

⊕ 1: to view the audio and video signal input through the Ö−1 connector on the rear.

 $\overset{\sim}{\sim}$ 1: to view the RGB signal (i.e. from a computer, etc.) input through the $\overset{\sim}{\circ}$ 1 connector.

⊕ 2: to view the audio and video signal input through the ⊕ 2/€- connector on the rear.

2: to view the S video signal (from a VTR equipped with

 Θ 3: to view the audio and video signal input through the Θ 3 connectors and the audio input jacks Θ (yellow, white and red) on the front. an S video output) input through the 3-2/6- connector.

You can also select the desired input mode using the buttons on the front of the set. Select the $\mathbb G$ -mode with the mode select ($\mathbb P\to \Delta\to \mathbb G$ +) button ($\mathbb G$) then press +/button.

To return to the TV mode, press the TV-button [16].

To select the signal to be output from the ⊕•2/ ⊕- connector

Press the ⊕ button in repeatedly until the desired output source is indicated on the screen:

1 ⊕: The audio and video signal input through the Ö-1 connectors is output from the 3-2/6- connector

2 ○ :The audio and video signal input through the ⊕•2/€ connector is output from the ⊕•2/€

3 \bigcirc : The audio and video signal input through the \bigcirc -3 connectors is output from the \bigcirc -2 \bigcirc - connector.

TV G+: The audio and video signal input through the Tr aerial terminal (i.e. usually the TV signal) is output from the ♣ 2/♠ connector.

The indication will disappear after a few seconds.

Note

The TV-signal is always output at the EURO-AV connector 쯘-1.

To operate Sony video equipment
The video operation buttons and the Remote Commander
can operate certain VTRs and video disc players

1. Switch the video selector to the desired position.

VIDEO 1: to operate Sony Betamax VTR and SLV 202 VHS.
VIDEO 2: to operate Sony 8 mm VTR.
VIDEO 3: to operate Sony VHS VTR.

MDP: to operate Sony video disc player including a multi manufactured by Sony

2. Press the operation button(s) to start operation. PROGR +/-: to select the desired programme on the VTR.

to start playback, or to release the pause mode

: to stop the tape or the disc

to rewind the tape from stop mode or to rapidly go back to the desired position on the disc or tape from playback mode ¥


to fast forward wind from stop mode or rapidly advance the tape or disc to the desired position from playback mode 1

Be sure to press this button and the one on the right to start recording on the VTR •

to switch the video equipment on and off Ð

to stop the tape or the disc temporarily (pause) Press again to release pause mode :

1-5. CONNECTING OTHER EQUIPMENT



Connect the S video output of the VTR, etc. here.

Notes

- It is also possible to connect a VTR using the 'IT terminal. In this case, connect the aerial to the aerial terminal of the
- Move the VTR away from the TV if the picture or the sound
 - is distorted.

 Computers which have RGB output only can be connected to the 😤-1 input connector.

S video input (Y/C input) & ...

Video signals may be separated into Y (luminance or brightness) and C (chrominance) signals.

Usually these wo signals are combined in a VTR and output as one signal, and supplied to a TV. Separation of the Y and C signals prevents them from interfering with one another, thereby improving picture quality (especially in luminance). This set is equipped with a S video input through which these separated signals can be input directly.

Connect the S video output jack on the VTR to the S video input on this set.


Note: Not all VTR's are equipped with S video output capability. (Refer to VTR operating manual.)

-8-


SECTION 2 DISASSEMBLY

2-1. REAR COVER REMOVAL


2-2. CHASSIS ASSEMBLY REMOVAL



2-3. A AND J1 BOARDS REMOVAL




2-4. B AND V BOARDS REMOVAL




2-5. SERVICE POSITION

* Remove the connector bracket and then perform the following servicing. (Refer to 2-2. CHASSIS ASSEMBLY REMOVAL.)





Remoce main chassis in the arrow direction.





· REMOVAL OF ANODE-CAP

REMOVING PROCEDURES










③ When one side of the rubber cap is separated from the anode button, the snode-cap can be removed by turning up the rubber cap and pulling up it in the direction of the arrow ©.

· HOW TO HANDLE AN ANODE-CAP

- Don't hurt the surface of anode-caps with sharp shaped material!
- ② Don't press the rubber hardly not to hurt inside of anode-caps! A material fitting called as shatter-hook terminal is built in the rubber.
- ③ Don't turn the foot of rubber over hardly! The shatter-hook terminal will stick out or hurt the rubber.





SECITON 3 SET-UP ADJUSTMENTS

- When complete readjustment is necessary or a new picture tube is installed, carry out the following adjustments.
- Unless there is specific instruction to the contrary, carry out these adjustments with the rated power supply.
- Unless there is specific instruction to the contrary, set the controls and switches this way:

① Contrast80%

(or remote control normal)

⇔ Brightness ······50%

- Carry out the following adjustments in this order:
 - 1. Beam landing
 - 2. Convergence
 - 3. Focus
 - 4. White balance

Note: Testing equipment required

- 1. Color bar/pattern generator
- 2. Degausser
- 3. DC power supply
- 4. Digital multimeter
- 5. Oscilloscope

Preparations:

- In order to reduce the influence of geomagnetism on the set's picture tube face it east or west.
- Switch on the set's power and degauss with the degausser.


3-1. BEAM LANDING

- 1. Input the white signal with the pattern generator.

 Contrast
 Bightness normal
- 2. Set the pattern generator raster signal to red.
- 3. Move the deflection yoke to the rear and adjust with the purity control so that the red is at the center and the blue and the green take up equally sized areas on each side.

(See Figures 3-1 through 3-3.)

- 4. Move the deflection yoke forward and adjust so that entire screen is red. (See Figure 3-1.)
- 5. Switch the raster signal to blue, then to green and verify the condition.
- When the position of the deflection yoke has been decided, fasten the deflection yoke with the screws.
- 7. If the beam does not land correctry in all the corners, use a magnet to adjust it.(See Figure 3-4.)






Fig. 3-2




Fig. 3-3





Fig. 3-4

3-2. CONVERGENCE

Preparations:


- Before starting this adjustment, adjust the focus, horizontal size, and vertical size.
- Minimize the brightness setting.
- Provide dot pattern.
- (1) Horizontal and vertical static convergence




- (Moving horizontally), adjust the H.STAT control so that the red, green, and blue points are on top of each other at the center of the screen.
- 2. (Moving vertically), adjust the V.STAT magnet so that the red, green, and blue points are on top of each other at the center of the screen.
- 3. If the H.STAT variable resistor can not bring the red, green, and blue points together at the center of the screen, adjust the horizontal convergence with the H.STAT variable resistor and the V. STAT magnet in the manner given below.


 (In this case, the H.STAT variable resistor and the V.STAT magnet influence each other's settings.)


 Tilt the V.STAT magnet and adjust the static convergence by opening or closing the V.STAT magnet.




4. If the V.STAT magnet is moved in the direction of the (a) and (b) arrows, the red, green, and blue points move as shown below.










• Operation of BMC (Hexapole) Magnet



 The respective dot operations resulting from the operation of each magnet are not completely independent, so be sure to perform adjustment while tracking.

Use the H.STAT VR to adjust the red, green, and blue dots so they coincide at the center of screen (by moving the dots in the horizontal direction).



Before starting this adjustment, adjust the horizontal static convergence and the vertical static convergence.

- 1. Slightly loosen the deflection yoke screws.
- 2. Remove the deflection yoke spacer.


Move the deflection voke as shown in the fi

Purity


- 3. Move the deflection yoke as shown in the figure below and optimize the convergence.
- 4. Tighten the deflection yoke screws.

V. STAT


5. Install the defelection yoke spacer.



(3) Screen corner convergence







3-4. WHITE BALANCE

[Screen G2 setting]

- 1. Input the dot signal from the pattern generator.
- 2. Set the picture brightness control to its lowest level.
- 3. Apply 170V DC to the R, G, and B cathodes with an external power supply.
- 4. While watching the picture, adjust G2 control RV701 (Screen) to the point just before the return lines disappear.


[White balance adjustment]

- 1. Input an all-white signal from the pattern generator.
- 2. Set the picture brightness and color controls to their normal levels.
- 3. Use the RV704 (B Drive) and RV703 (G Drive) to adjust white balance.

In the adjustments below, have the picture color and brightness settings at their normal levels unless there is a specific instruction to the contrary.

SECTION 4 CIRCUIT ADJUSTMENTS


4-1. A BOARD ADJUSTMENT



TUNER AGC ADJUSTMENT (VIF101, RV1)

- 1. Align with an appropriate signal between stations.
- 2. Adjust RV1 so that snow noise and cross modulation just disappear from the picture.

4-2. B BOARD ADJUSTMENTS



(COMPONENT SIDE)

REFERENCE OSCILLATOR ADJUSTMENT (CT332 8.8MHz)


- 1. Input a PAL color bar signal.
- 2. Ground pin n of the IC331.
- 3. Adjust CT332 to obtain synchronization.

REFERENCE OSCILLATOR ADJUSTMENT (CT331 7.16MHz)

- 1. Input an NTSC color bar signal.
- 2. Ground pin ® of IC331.
- 3. Adjust the CT331 to obtain synchronization.
- 4. Remove the jumper grounding pin ① of IC331.


BELL FILTER ADJUSTMENT (L336)

- 1. Input a SECAM color bar signal.
- 2. Connect the oscilloscope to the emitter of Q335.
- 3. Adjust L336 so that the waveform is flat.




DISCRIMINATION ADJUSTMENT (RV331 and L331)

- 1. Input a SECAM color bar signal.
- 2. Connect the oscilloscope to pin ① of IC331.
- Adjust RV331 so that the white and black sections of the waveform at pin ① come to the 0 level.
- 4. Connect the oscilloscope to pin 3 of IC331.
- 5. Adjust L331 so that the white and black sections of the waveform at pin 3 come to the 0 level.



4-3. D BOARD ADJUSTMENTS



+B ADJUSTMENT (RV501)


- 1. Connect the digital multimeter to TP91.
- 2. Adjust RV501 to obtain 135 ± 0.2 V.

ST-BY +B ADJUSTMENT (RV601)

- 1. Put the system into \circlearrowleft standby mode (remote commander).
- 2. Connect the digital multimeter to TP91.
- 3. Adjust RV601 to obtain $135 \pm 3V$.
- 4. Take the system out of \circlearrowleft standby mode (remote commander).

H.PHASE ADJUSTMENT (RV502)


- 1. Input a PAL color bar signal.
- 2. Set the picture and brightness controls to their normal levels.
- 3. Set RV1508 (H.CENT) to its mechanical center.
- 4. Connect the oscilloscope to pin (I) (SCP) of IC 501.
- 5. Rotate RV502 to adjust to $H\pm0.1\mu s$. See below table for the H value.




Standard of H.Phase


Model Size	Н
21"	5.6μ s
25"	5.1μ s
29"	5.5μ s

4-4. J1 BOARD ADJUSTMENTS





4-5. V BOARD ADJUSTMENTS



CLOCK ADJUSTMENT (CT01)

- 1. Remove the pin 3 of V-01 connector.
- 2. Put the system into text mode.
- 3. Adjust CT01 so that the picture does not move.

RGB LEVEL ADJUSTMENT (RV01)

- 1. Maximize the picture setting.
- 2. Adjust RV01 so that the RGB output is 0.75V.

4-6. SECONDARY ADJUSTMENT

SUB BRIGHTNESS ADJUSTMENT

- 1. Set the system to receive a test pattern.
- Press → ← on the remote commander to put the system into normal mode.
- 3. Switch off the power.
- While depressing the adjusting buttons + and
 simultaneusly, turn on the power. (SUB mode is obtained)
- 5. Minimize the ① contrast setting.
- 6. Adjust the \$\footnote{\text{the}}\$ brightness control so that the gray scale 0 IRE section is cut off completely and the 20 IRE section is barely glowing.
- 7. Depress the (store) button of the remote commander.(SUB mode is released)


If there is no test color pattern

- 1. Set the system to receive a color pattern.
- Press on the remote commander to put system into normal mode.
 Set the color to its normal state.
- 3-5. are the same as above.
- 6. Since 20 IRE is nearly blue, adjust the ☆ brightness control so that the blue barely glows.
- 7. is the same as above.
- Press → ← on the remote commander to put the system into normal mode.


SECTION 5 DIAGRAMS


SUB COLOR ADJUSTMENT

- 1. Set the system to receive color bars.
- Press → ← on the remote commander to put the system into normal mode.
- 3. Cut off the power.
- 4. While depressing the adjustment buttons + and simultaneusly, turn on the power. (SUB mode is obtained)
- 5. Adjust the color control so that the B out waveform (pin 2) of C board connector CNC72) is as shown in the figure below.
- 6. Depress the \diamondsuit (store) button of the remote commander. (SUB mode is released)




5-1. BLOCK DIAGRAM





5-2. CIRCUIT BOARDS LOCATION



Note: The components identified by shading and mark

A are critical for safety. Replace only with
part number specified.

Note:

- All capacitors are in μF unless otherwise noted. pF: $\mu \, \mu F$ 50WV or less are not indicated except for electrolytics.
- Indication of resistance, which does not have one for rating electrical power, is as follows.

Pitch: 5mm
Rating electrical power: 1/4W

- Chip resistor is in 1/10W.
- All resistors are in ohms. $k\Omega = 1000\Omega$, $M\Omega = 1000k\Omega$
- monflammable resistor.
- fusible resistor.
- △: internal component.
- panel designation and adjustment for repair.
- All variable and adjustable resistors have characteristic curve B.unless otherwise noted.
- All voltages are in V.
- Readings are taken with a $10M\Omega$ digital multimeter.
- Readings are taken with a color-bar signal input.
- Voltage variations may be noted due to normal production tolerances.
- - : B + line.
- signal path.

Reference information

ALR

METAL FILM RESISTOR : RN SOLID RC NONFLAMMABLE CARBON : FPRD NONFLAMMABLE FUSIBLE : FUSE NONFLAMMABLE METAL OXIDE : RS NONFLAMMABLE CEMENT · RR NONFLAMMABLE WIREWOUND ADJUSTMENT RESISTOR COIL : LF-8L MICRO INDUCTOR CAPACITOR : TA **TANTALUM** PS STYROL POLYPROPYLENE : PP : PT MYLAR METALIZED POLYESTER : MPS METALIZED POLYPROPYLENE : MPP : ALB BIPCLAR HIGH TEMPERATURE : ALT

HIGH RIPPLE

5-3. SCHEMA

H2

[SIRCS RECEIVER, INDICATOR]



[LINE FILTER, DGC]


5-3. SCHEMATIC DIAGRAMS AND PRINTED WIRING BOARDS

-Conductor Side-


CONTROL SW,

AV INPUT, HEADPHONE


-H1 Board-




-H2 Board-



-F Board-



−A Board−




[TUNER, SIF, VIF]

AUDIO CONTROL, AV INPUT Y/C INPUT, SCAR VIDEO OUT EAST-WEST CORRECTION


J2

SPEAKER TERMINAL


—A Board—





-J1 Board-





-J2 Board-














TO D BOARD D-2


• WAVEFORMS D BOARD




D BOARD IC501 TEA2020B












D BOARD IC501 TEA2020B




M

D BOARD IC601 TEA2260








KV-C2521D/C2531D RM-689 KV-C2521D/C2531D RM-689

[TUNING CONTROL, POWER CONTROL,]

D






· .		DOOG	F 1
	С	D006 D007	F-1 A-1
IC001	B-2	D009	E-1
IC002 IC003	D-2 C-1	D010 D011	G – 1 G – 1
IC005	G-2	D271	C-4
IC251 IC261	F-4 C-4	D272 D501	D-5 G-6
IC501	G-6	D504	G−6 E−5
IC502	E-5	D506	F-5
IC601 IC604	A-6 A-4	D508 D509	G-5 D-6
IC608	A-3	D511	E-6
		D512 D513	E-5 E-5
TRANS	SISTOR	D601	A-8
		D602	C-6
Q001 Q002	A-2 B-1	D603 D604	A-6 A-5
0003	D-1	D605	B-6
Q004 Q005	D-1 C-1	D606 D607	B-6 B-6
0006	B-1	D608	C-7
Q007	C-1	D609	B-6
Q008	C-1 C-2	D610 D611	C-4 D-6
Q251	E-4	D612	B-5
Q261 Q271	D-4 C-5	D613 D614	A-5 A-5
Q502	F-6	D614	D-5
Q505	E-6	D617	A-6
Q506 Q507	E-6 G-5	D618 D619	D-5 B-6
Q598	G-1	D620	D-5
Q601	B-4	D621	B-6
Q602 Q603	C-8 C-4	D622 D623	D-5 B-4
Q604	A-6	D624	B-4
Q605	D-5 C-4	D630 D801	D-5 F-8
Q606 Q607	D-5	D801	F-0 F-10
Q608	C-4	D803	G-10
Q609 Q801	C-4 G-4	D804 D805	E-7 E-7
Q804	E-10	D805	E-7 E-9
Q805	F-7	D807	E-10
		D808	D-9
DIC	ODE		
D001	B-2		IABLE STOR
D002	A-2		
D003	A-2 C-2	RV501 RV502	F-5 G-7
D005	G-1	RV601	A-7









IC		D006 D007	F-1 A-1
IC001 IC002	B-2 D-2	D009 D010	E-1 G-1
IC003	C-1	D011	G-1
IC005	G-2	D271	C-4
IC251	F-4	D272	D-5
IC261 IC501	C-4 G-6	D501 D504	G-6 E-5
IC502	E-5	D504	F-5
IC601	A-6	D508	G-5
IC604	A-4	D509	D-6
IC608	A-3	D511 D512	E-6 E-5
		D513	E-5
TRAN	SISTOR	D601 D602	A-8 C-6
Q001	A-2	D603	A-6
Q002	B – 1 D – 1	D604	A-5
Q003 Q004	D-1 D-1	D605 D606	B-6 B-6
Q005	C-1	D607	B-6
Q006	B-1	D608	C-7
Q007	C-1	D609	B-6
Q009	C-1 C-2	D610 D611	C-4 D-6
Q251	E-4	D612	B-5
Q261	D-4	D613	A-5
Q271 Q502	C-5 F-6	D614	A-5
Q505	E-6	D616 D617	D-5 A-6
Q506	E-6	D618	D-5
Q507	G-5	D619	B-6
Q598	G-1	D620	D-5
Q601 Q602	B-4 C-8	D621 D622	B-6 D-5
Q603	C-4	D623	B-4
Q604	A-6	D624	B-4
Q605	D-5	D630	D-5
Q606 Q607	C-4 D-5	D801 D802	F-8 F-10
Q608	C-4	D803	G-10
Q609	C-4	D804	E-7
Q801	G-4	D805	E-7
Q804 Q805	E-10 F-7	D806 D807	E-9 E-10
4000	' '	D808	D-9
DIODE			
D001	B-2		IABLE
D001	A-2	KESI	STOR
D003	A-2	RV501	F-5
D004	C-2 G-1	RV502	G-7 A-7
D005	G-1	RV601	A-1




NOTE:


The circuit indicated as left contains high voltage of over 600 Vp-p. Care must be paid to prevent an electric shock in inspection or repairing.


WAVEFOR

4

إسائ PAL, SECAM 4.8Vp-p (









• WAVEFORMS B BOARD

		2		(3) • • • • • • • • • • • • • • • • • • •	ENTA ENTA
PAL, SECAM 4.8Vp-p (H)	NTSC 3.58/4.43 4.8 Vp-p(H)	PAL, SECAM 4.8 Vp-p (H)	NTSC 3.58/4.43 4.8Vp-p (H)	PAL, SECAM 4.8Vp-p (H)	NTSC 3.58/4.43 4.8Vp-p (H)
(4) N N	(5)	(5)	(5)	6	6
	PAL PAL	SECAM	NTSC 3.58/4.43	PAL. SECAM	NTSC 3.58/4.43
1 Vp-p (H)	0.4Vp-p (H)	0.36 Vp-p(H)	0.46Vp-p (H)	0.9Vp-p(H)	0.7Vp-p (H)
7 — — — — — — — — — — — — — — — — — — —					9
PAL, SECAM	NTSC 3.58/4.43	PAL (0.5 Vp-p (H)	SECAM	NTSC 3.58/4.43	— Лу-Лу-Лу PAL 0.6Vp-p (Н)
9	9, ,,,,,	10		12	(12)
_#\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\					The Assertation of the
SECAM 1.3Vp-p (H)	NTSC 3.58/4.43 0.6 Vp-p(H)	SECAM 1.4 Vp-p (H)	SECAM 0.2Vp-p(H)	PAL 0.2Vp-p (H)	SECAM 0.12Vp-p (H)
12	(3)	13	(13)	14	14
			Lapone Lapone La	4/100 A	Shape Shape
NTSC 3.58/4.43 0.05Vp-p (H)	PAL 0.4Vp-p (H)	SECAM 0.1 Vp-p(H)	NTSC 3.58/4.43 0.4 Vp-p (H)	PAL 1 Vp-p (H)	SECAM 1 Vp-p (H)
14	(15)	15	(15)	16	16
-party	7	San Parks		ما كمسمس الم	-p ¹
NTSC 3.58/4.43 .1Vp-p (H)	PAL 1 Vp-p (H)	SECAM 0.9Vp-p (H)	NTSC 3.58/4.43 1 Vp-p(H)	PAL, SECAM O.4Vp-p (H)	NTSC 3.58/4.43 0.54Vp-p (H)


	PAL	SECAM	NTSC3.58	NTSC4.43
10301 📵	0.1	0.1	5.8	0.1
(26)	6.7	6.8	5.1	5.1
10331 (B	3.1	3.6	3.1	2.8
(21)	3.0	3.5	2.9	2.7
\overline{u}	5.6	5.6	7.1	7.2
23	7.5	7.0	5.6	5.6
(25)	0.1	0.1	0.1	5.8
(26)	0.1	0.1	5.8	0.1
\overline{v}	0.1	5.8	0.1	0.1
(28)	5.9	0.1	0.1	0.1
Q331 (B)	0.1	0.1	5.8	0.1
(C)	1.5	1.9	0	0.8
Q333 (B)	3.4	4.4	4.4	4.4
Q334 (B)	4.9	0.1	4.8	4.8
Q335 (B)	0.1	4.8	0.1	0.1
Q336 (B)	0.1	5.8	0.1	0.1
(C)	7.3	0	7.3	7.3




-B Board-




B BOARD IC301 TDA4580




-V Board-







• WAVEFORMS V BOARD




[R·G·B OUT]

-C Board-







• WAVEFORMS C BOARD






-IFG Board-





5-4. SEMICONDUCTORS



SECTION 6 EXPLODED VIEWS


NOTF .

- Items with no part number and no description are not stocked because they are seldom required for routine service.
- The construction parts of an assembled part are indicated with a collation number in the remark column.
- Items marked " * " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

The components identified by shading and mark \triangle are critical for safety. Replace only with part number specified.


6-1. CHASSIS

- ●:BVTP3×12 7-685-648-79
- ■: BTVP4×16 7-685-663-79



REF.NO. PART NO. DESCRIPTION	REMARK REF.	NO. PART NO.	DESCRIPTION	REMARK
1 4-809-913-99 FOOT, F 2 4-394-305-01 BUTTON, POWER 3 *1-633-410-11 H2 BOARD 4 *1-633-408-11 F BOARD 5	13 14 15 16 17 18 19 20 21 20 21 22	*A-1347-031-A *A-1621-010-A *-364-802-00 *1-633-411-11 *A-1632-005-A A. 1-465-301-11 *A-1654-003-A 4-386-618-01 4-200-224-01 4-200-224-11	A BOARD, COMPLETE TUNER, ET (UV-816(PLL)) IFG BOARD, COMPLETE	

6-2. PICTURE TUBE





SECTION 7 ELECTRICAL PARTS LIST

NOTE:

Items marked " * " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

 All variable and adjustable resistors have characteristic curve B, unless otherwise noted.

When indicating parts by reference number, please include the board name.

CAPACITORS • MF : μF, PF : μμF

COILS • MMH : ιπΗ, UH : μΗ The components identified by shading and mark \triangle are critical for safety cal for safety. Replace only with part number specified.

RESISTORS

All resistors are in ohms
F: nonflammable

REF.NO. PART NO.	DESCRIPTION		REMARK	REF.NO	. PART NO.	DESCRIPTIO	N -	REMARK
*A-1347-031-A						DE>		
	V BOARD, COMPLETE ******************** CASE (UPPER LID), SHIE PACITOR	LD, A1		D01 D02 D03 D04 D07	8-719-105-91 8-719-106-79 8-719-400-18 8-719-105-52 8-719-106-17	DIODE RD13M DIODE MA152 DIODE RD3.6	-B1 WK M-B2	
C02 1-124-120-11 C03 1-124-119-00 C05 1-126-101-11 C06 1-124-120-11 C07 1-124-791-11	ELECT 330MF ELECT 100MF	20% 20% 20% 20% 20%	16V 16V 16V 16V 50V	D08 D09 D10 D11 D12	8-719-106-17 8-719-400-18 8-719-400-18 8-719-914-44 8-719-914-44	DIODE MA152 DIODE MA152 DIODE DAP20	WK WK 2K	
C08 1-163-097-00 C09 1-163-141-00 C10 1-163-133-00 C11 1-163-037-11 C12 1-163-127-00	CERAMIC CHIP 0.001MF CERAMIC CHIP 470PF CERAMIC CHIP 0.022MF	5% 5% 5% 10%	50V 50V 50V 25V 50V	1C1 1C2	<1C2 8-759-986-92 8-759-972-96	IC MAB-8461		
C13	CERAMIC CHIP 15PF CERAMIC CHIP 27PF CERAMIC CHIP 0.01MF	5% 5% 5% 10%	50V 50V 50V 50V 25V	1C3 1C4	8-759-032-98 8-759-230-68	1C TMM2063P L>		
C18	CERAMIC CHIP 0.047MF CERAMIC CHIP 220PF CERAMIC CHIP 0.068MF	5% 10% 5% 20%	50 V 25 V 50 V 25 V 16 V	L01 L04 L05 L06	1-408-411-00 1-408-407-00 1-408-407-00 1-408-407-00	I NDUCTOR I NDUCTOR I NDUCTOR I NDUCTOR	15UH 6.8UH 6.8UH 6.8UH	
C25 1-124-477-11 C27 1-163-129-00 C28 1-163-137-00 C29 1-124-927-11 C51 1-163-038-00	CERAMIC CHIP 330PF CERAMIC CHIP 680PF ELECT 4.7MF	20% 5% 5% 20%	16V 50V 50V 50V 25V	PS01 A	∆.1-532-679-91 ∆.1-532-727-91	LINK, IC 0.2	CP-N15) 0.6A 25A	
C52 1-163-038-00 C53 1-163-038-00 C54 1-163-038-00 C55 1-163-038-00 C56 1-163-038-00	CERAMIC CHIP 0.1MF CERAMIC CHIP 0.1MF CERAMIC CHIP 0.1MF		25V 25V 25V 25V 25V	Q3 Q01 Q02 Q04 Q05	8-729-900-53 8-729-107-26 8-729-807-50 8-729-271-22 8-729-807-50	TRANSISTOR 2 TRANSISTOR 2 TRANSISTOR 2	2SD1585-K 2SD1623-R 2SC2712-G	
C58	CERAMIC CHIP 0.001MF CERAMIC CHIP 0.001MF CERAMIC CHIP 0.001MF	5% 5% 5%	50V 50V 50V	Q06 Q07 Q09 Q10	8-729-271-22 8-729-900-98 8-729-807-87 8-729-807-87 8-729-807-87	TRANSISTOR 2 TRANSISTOR 2 TRANSISTOR 2 TRANSISTOR 2	2SC2712-G DTC143TK 2SB1295-UL6 2SB1295-UL6	
CNV02 *1-565-393-11	CONNECTOR, BOARD TO BOACONNECTOR, BOARD TO BOA	ARD				ISTOR>		
CNV03 *1-508-784-00	PIN, CONNECTOR (5MM PI)	TCH) 1P		JW1 JW2	1-216-295-00	METAL GLAZE	0 5% 0 5%	1/100
	MMER> CAP, VAR, TRIMMER (1 GA	ANG)		JW3 JW4 JW5	1-216-295-00 1-216-295-00 1-216-295-00 1-216-295-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 5% 0 5% 0 5% 0 5%	1/10W 1/10W 1/10W 1/10W
	(1 4)			JW6	1-216-295-00	METAL GLAZE	0 5%	1/10W



REF.NO.	PART NO.	DESCRIPTION			REMARK	REF.NO.	PART NO.	DESCRIPTION			REMARK
JW7 JW8 JW10 JWI1	1-216-295-00 1-216-295-00 1-216-295-00 1-216-295-00 1-216-295-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 5% 0 5% 0 5% 0 5% 0 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R64 R65 R66 R67	1-216-065-00 1-216-065-00 1-216-057-00 1-216-057-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	4.7K 5% 4.7K 5% 2.2K 5% 2.2K 5% 2.2K 5% 2.2K 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
JW12 JW13 JW14 JW15 JW16	1-216-295-00 1-216-295-00 1-216-295-00 1-216-295-00 1-216-295-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 5% 0 5% 0 5% 0 5% 0 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R68 R69	1-216-057-00 1-216-057-00 <var 1-238-012-11</var 	METAL GLAZE METAL GLAZE IABLE RESISTOR	? >	1/100	
JW17 JW18 JW19 JW20 JW21	1-216-295-00 1-216-295-00 1-216-295-00 1-216-295-00 1-216-295-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 5% 0 5% 0 5% 0 5% 0 5%	1/10W 1/10W 1/10W 1/10W 1/10W		X01		STAL>	CRYSTAL		
JW22 JW23 JW24 JW25 ROI	1-216-295-00 1-216-295-00 1-216-295-00 1-216-295-00 1-218-326-11	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 5% 0 5% 0 5% 0 5% 470 5%	1/10W 1/10W 1/10W 1/10W 1/2W		X02 X03	1-507-493-11 1-577-082-11 ***********************************	VIBRATOR, CE	RAMIC *********	* ** ***	******
R02	1-216-065-00	METAL GLAZE	4.7K 5%	1/10W			11 1021 010 11	********	****		
R04 R05 R06 R07	1-218-326-11 1-216-025-00 1-216-049-00 1-216-025-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	470 5% 100 5% 1K 5% 100 5%	1/2W 1/10W 1/10W 1/10W		; 1 1 1 1	*1-565-393-11 *1-568-881-51			RD .	
R08	1-216-037-00	METAL GLAZE	330 5%	1/10W				ACITOR>	0.0045	109/	1004
R09 R13 R14 R15	1-216-091-00 1-216-025-00 1-216-025-00 1-216-121-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	56K 5% 100 5% 100 5% 1M 5%	1/10W 1/10W 1/10W 1/10W		C301 C302 C303 C304 C305	1 · 106 - 228 - 00 1 · 106 - 228 - 00 1 · 124 - 122 - 11 1 · 106 - 228 · 00 1 - 124 - 119 - 00	MYLAR MYLAR ELECT MYLAR ELECT	0.22MF 0.22MF 100MF 0.22MF 330MF	10% 10% 20% 10% 20%	100V 100V 50V 100V 16V
R16 R17 R18 R19 R20	1-216-055-00 1-216-049-00 1-216-065-00 1-216-037-00 1-216-063-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	1.8K 5% 1K 5% 4.7K 5% 330 5% 3.9K 5%	1/10W 1/10W 1/10W 1/10W 1/10W		C306 C307 C308 C309 C310	1-124-902-00 1-124-902-00 1-124-902-00 1-124-902-00 1-106-220-00	ELECT ELECT ELECT ELECT MYLAR	0.47MF 0.47MF 0.47MF 0.47MF 0.1MF	20% 20% 20% 20% 10%	50V 50V 50V 50V 100V
R27 R28 R29 R30 R31	1-216-013-00 1-216-013-00 1-216-013-00 1-218-325-11 1-218-325-11	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	33 5% 33 5% 33 5% 120 5% 120 5%	1/10W 1/10W 1/10W 1/4W 1/4W		C311 C312 C313 C314 C315	1-106-220-00 1-124-902-00 1-124-902-00 1-124-902-00 1-124-791-11	MYLAR ELECT ELECT ELECT ELECT	0.1MF 0.47MF 0.47MF 0.47MF	10% 20% 20% 20% 20%	100V 50V 50V 50V 50V
R32 R33 R34 R37 R38	1-218-325-11 1-216-023-00 1-216-049-00 1-216-025-00 1-216-047-00	METAL GLAZE METAL GLAZE	120 5% 82 5% 1K 5% 100 5% 820 5%	1/4W 1/10W 1/10W 1/10W 1/10W		C316 C317 C318 C320 C321	1-106-220-00 1-124-910-11 1-106-220-00 1-163-121-00 1-163-127-00	MYLAR	0.1MF 47MF 0.1MF 150PF 270PF	10% 20% 10% 5%	100V 50V 100V 50V 50V
R40 R41 R43 R44 R45	1-216-065-00 1-216-041-00 1-216-065-00 1-216-041-00 1-216-049-00	METAL GLAZE METAL GLAZE METAL GLAZE	4.7K 5% 470 5% 4.7K 5% 470 5% 1K 5%	1/10W 1/10W 1/10W 1/10W 1/10W		C322 C323 C327 C330 C331	1-163-121-00 1-102-947-00 1-164-232-11 1-163-113-00 1-106-220-00	CERAMIC CHIP CERAMIC CERAMIC CHIP CERAMIC CHIP MYLAR	10PF 0.01 M F	5% 0.5PF 5% 10%	50V 50V 50V 50V 100V
R46 R51 R52 R53 R54	1-216-311-00 1-216-065-00 1-216-065-00 1-216-065-00 1-216-065-00	METAL GLAZE METAL GLAZE	6.8 5% 4.7K 5% 4.7K 5% 4.7K 5% 4.7K 5%	1/10W 1/10W 1/10W 1/10W 1/10W		C332 C333 C334 C335 C336	1-126-103-11 1-106-375-12 1-163-097-00 1-163-097-00 1-102-816-00	ELECT MYLAR CERAMIC CHIP CERAMIC CHIP CERAMIC		20% 10% 5% 5%	16V 250V 50V 50V 50V
R55 R56 R57 R58 R59	1-216-057-00 1-216-065-00 1-216-065-00 1-216-061-00 1-216-069-00		2.2K 5% 4.7K 5% 4.7K 5% 3.3K 5% 6.8K 5%	1/10W 1/10W 1/10W 1/10W 1/10W		C337 C338 C339 C341 C343	1-101-004-00 1-106-220-00 1-106-220-00 1-163-125-00 1-106-383-00	CHRAMIC MYLAR MYLAR CERAMIC CHIP MYLAR	0.01MF 0.1MF 0.1MF	10% 10% 5% 10%	50 V 100 V 100 V 50 V 100 V
R60 R61 R62 R63	1-216-076-00 1-216-083-00 1-216-065-00 1-216-065-00	METAL GLAZE METAL GLAZE	13K 5% 27K 5% 4.7K 5% 4.7K 5%	1/10W 1/10W 1/10W 1/10W		C344 C345 C346	1-130-783-00 1-163-123-00 1-163-033-00	MYLAR CERAMIC CHIF CERAMIC CHIF	0.33MF 180PF	10% 5%	100V 50V 50V

REF.NO	. PART NO.	DESCRIPTION		REMARK	REF.NO.	PART NO.	DESCRIPTION			REMARK
C347 C348 C349 C350 C351	1 124-791-11 1-124-791-11 1-101-004-00 1-101-004-00 1-106-375-12	BLECT	20% 20%	50V 50V 50V 50V 250V	DL401	1-415-613-11 <ic></ic>	DELAY LINE,	Y		
C352 C353 C354 C357 C358	1-124-910-11	CERAMIC CHIP 0.022MF ELECT 47MF CERAMIC CHIP 100PF	10% 10% 20% 5% 20%	250V 50V 50V 50V 50V	10302 10303 10331	8-759-979-85 8-759-980-60 8-759-040-53 8-759-990-29 8-759-990-30	IC TDA8442N3 IC MCI4053BC IC TDA4650			
C359 C360 C364 C365 C366	1-101-004-00	CERAMIC CHIP 33PF ELECT 47MF	5% 5% 20% 20%	50 V 50 V 50 V 50 V 16 V	L301 L302 L303 L331	1-410-868-11 1-410-868-11 1-408-408-00 1-404-554-11	INDUCTOR INDUCTOR INDUCTOR	4.7UH 4.7UH 8.2UH		
C367 C381 C382 C384 C385	1-101-004-00 1-124-902-00 1-124-927-11 1-124-910-11 1-124-927-11	ELECT 0.47MF ELECT 4.7MF ELECT 47MF	20% 20% 20% 20%	50V 50V 50V 50V 50V	L336 L338 L1301	1 -404 -554 -11 1 -408 -409 -00 1 -408 -425 -00 1 -408 -419 -00	COIL INDUCTOR INDUCTOR	10UH 220UH 68UH		
C386 C387 C388	1-124-927-11 1-130-833-00 1-106-220-00	MYLAR 0.82MF	20% 10% 10%	50V 63V 100V		<tra< td=""><td>NSISTOR</td><td></td><td></td><td></td></tra<>	NSISTOR			
C401 C402		CERAMIC 150PF CERAMIC CHIP 470PF	5% 5%	50V 50V	Q301 Q303 Q305	8-729-271-22 8-729-901-00	TRANSISTOR 2 TRANSISTOR 2 TRANSISTOR D	SC2712-G TC124EK		
C1312	1-16 3-11 1-00 1-16 3-10 1-00	CERAMIC CHIP 0.01MF CERAMIC CHIP 56PF CERAMIC CHIP 22PF	5% 5% 5%	50V 50V 50V	Q306 Q311	8-729-271-22	TRANSISTOR 2 TRANSISTOR 2	SC2712-G	Œ	
01313	1-102-953-00 <tri< td=""><td>CERAMIC 18PF MMER></td><td>24</td><td>50V</td><td>Q312 Q313 Q316 Q330</td><td></td><td>TRANSISTOR 2: TRANSISTOR 2: TRANSISTOR 2: TRANSISTOR 2:</td><td>SC2712-G SC2712-G</td><td></td><td></td></tri<>	CERAMIC 18PF MMER>	24	50V	Q312 Q313 Q316 Q330		TRANSISTOR 2: TRANSISTOR 2: TRANSISTOR 2: TRANSISTOR 2:	SC2712-G SC2712-G		
	1-141-418-11 1-141-418-11	CAP, ADJ			Q331 Q332	8-729-901-00	TRANSISTOR D	TC124EK		
	<010				Q333 Q334 Q335	8-729-216-22 8-729-271-22 8-729-271-22	TRANSISTOR 2: TRANSISTOR 2: TRANSISTOR 2:	SA1162-G SC2712-G SC2712-G		
D301 D302 D303 D304 D305	8-719-911-19 8-719-911-19	DIODE 188119 DIODE 188119			Q336 Q381 Q382 Q1301 Q1306	8-729-901-00 8-729-271-22		C124EK SC2712-G		
D307 D308 D309	8-719-929-24 8-719-911-19 8-719-911-19	DIODE HZS11NB3 DIODE ISS119 DIODE ISS119		i		<res< td=""><td>ISTOR></td><td></td><td></td><td></td></res<>	ISTOR>			
D310 D311	8-719-929-24 8-719-929-24	DIODE HZSTINB3 DIODE HZSTINB3			JR384 JR390 R301	1-216-295-00 1-216-295-00 1-249-409-11	METAL GLAZE METAL GLAZE CARBON	0 5 0 5 220 5	% 1/10W % 1/10W % 1/4W	
D312 D313 D314	8-719-929-24 8-719-911-19 8-719-911-19	DIODE HZS11NB3 DIODE 1SS119 DIODE 1SS119			R302 R303	1-249-409-11 1-249-409-11	CARBON CARBON		1/4W 1/4W	
D315 D316	8-719-911-19 8-719-911-19	DIODE ISSI19 DIODE ISSI19			R304 R305 R307	1-249-409-11 1-216-057-00 1-216-097-00	CARBON METAL GLAZE METAL GLAZE	220 5 2.2K 5 100K 5	% 1/4W % 1/10W % 1/10W % 1/8W	
D317 D318 D319 D320	8-719-911-19 8-719-911-19 8-719-911-19 8-719-911-19	DIODE ISS119 DIODE ISS119 DIODE ISS119 DIODE ISS119		} 		1-216-184-00 1-216-025-00 1-216-025-00	METAL GLAZE METAL GLAZE METAL GLAZE	100 5	% 1/10W	
D331 D332 D333	8-719-911-19 8-719-911-19 8-719-911-19	DIODE 188119 DIODE 188119 DIODE 188119		 	R311 R312 R313	1-216-025-00 1-249-409-11 1-216-081-00	METAL GLAZE CARBON METAL GLAZE	100 5 220 5 22K 5	1/10W 1/4W 1/10W	
D350		DIODE HZS5.6NB3		1 	R315	1-216-182-00 1-216-027-00	METAL GLAZE			
		AY LINE>			R317	1-216-027-00 1-216-027-00 1-249-429-11	METAL GLAZE METAL GLAZE CARBON	120 5 120 5 10K 5	% 1/10W % 1/10W % 1/10W % 1/4W % 1/4W	
DL332	1-236-062-11	MODULE, Y DELAY LINE			R319	1-249-409-11	CARBON	220 5	% 1/4W	

The components identified by shading and mark \triangle are critical for safety.

Replace only with part number specified.

В	F	A
	REMA	ARK

REF.NO.	PART NO.	DESCRIPTION			REMARK	REF.NO.	PART NO.	DESCRIPTION			REMARK
R320 R321 R322 R323 R324	1-216-198-00 1-216-057-00 1-216-055-00 1-249-422-11 1-249-429-11	METAL GLAZE METAL GLAZE METAL GLAZE CARBON CARBON	1K 5% 2.2K 5% 1.8K 5% 2.7K 5% 10K 5%	1/8W 1/10W 1/10W 1/4W 1/4W		R401 R402 R403 R404 R405	1-216-053-00 1-216-051-00 1-216-025-00 1-216-059-00 1-216-065-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	1.5K 5% 1.2K 5% 100 5% 2.7K 5% 4.7K 5% 3.3K 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R325 R328 R329 R330 R331	1-216-073-00 1-216-009-00 1-216-009-00 1-216-009-00 1-216-001-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	10K 5% 22 5% 22 5% 22 5% 10 5%	(1/10W (1/10W (1/10W		R406 R407 R410 R412 R1301	1-216-061-00 1-216-047-00 1-216-184-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	3.3K 5% 820 5% 270 5% 1.5K 5% 4.7K 5%	1/10W 1/10W 1/8W 1/10W 1/10W	
R332 R333 R334 R335 R336	1-216-184-00 1-216-121-00 1-216-073-00 1-247-852-11 1-216-061-00	METAL GLAZE METAL GLAZE METAL GLAZE CARBON METAL GLAZE	270 55 1M 55 10K 55 7.5K 55 3.3K 55	(1/10W (1/10W		R1305	1-216-001-00	METAL GLAZE	10 5%	1/10W	
R337 R338 R339 R340 R341	1-216-184-00 1-216-001-00 1-216-033-00 1-216-121-00 1-216-031-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	270 55 10 55 220 55 1M 55 180 55	7/8W 7/10W 7/10W 7/10W 1/10W		X331 X332	<cry< td=""><td>STAL> OSCILLATOR, COSCILLATOR, COSCILLATOR,</td><td>RYSTAL</td><td></td><td></td></cry<>	STAL> OSCILLATOR, COSCILLATOR,	RYSTAL		
R342 R344 R346 R347 R348	1-216-041-00 1-216-089-00 1-216-202-00 1-216-073-00 1-216-089-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	470 50 47K 50 1.5K 50 10K 50 47K 50	7/10W		*****	*1-633-408-11	**************************************	*********	·******	***** **
R349 R350 R351 R354 R355	1-216-045-00 1-216-045-00 1-216-033-00 1-216-033-00 1-216-061-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	680 5: 680 5: 220 5: 220 5: 3.3K 5:	% 1/10W % 1/10W		! ! ! !	*1-566-664-11 <fus • 1-532-350-11</fus 	E>			and the
R356 R358 R359 R360 R361	1-216-069-00 1-216-033-00 1-216-089-00 1-216-089-00 1-216-057-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	6.8K 5: 220 5: 47K 5: 47K 5: 2.2K 5	% 1/10W % 1/10W % 1/10W			1-533-230-11	TCH>	1001		
R362 R363 R364 R365 R366	I-216-065-00 I-216-055-00 I-216-059-00 I-216-047-00 I-216-059-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	4.7K 5 1.8K 5 2.7K 5 820 5 2.7K 5	% 1/10W % 1/10W % 1/10W		*****	**************************************	*******	*********** PLETE		
R367 R370 R372 R376 R377	I-216-033-00 I-216-033-00 I-216-023-00 I-249-429-11 I-216-043-00	METAL GLAZE METAL GLAZE METAL GLAZE CARBUN METAL GLAZE	220 5 220 5 82 5 10K 5 560 5	% 1/10W % 1/4W		1	*1-560-290-00 *1-564-881-11 *1-564-886-11 *1-565-393-11 *1-565-503-11	PLUG, CONNECT PLUG CONNECT	ror 4P ror 9P Bard to Boa	RD	
R378 R379 R380 R381 R382	1 · 216 - 097 · 00 1 - 216 - 089 - 00 1 · 216 - 071 - 00 1 - 216 - 093 - 00 1 - 216 - 103 - 00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	100K 5 47K 5 8.2K 5 68K 5 180K 5	% 1/10W		C101 C102 C104	<cap 1-126-233-11 1-126-103-11 1-124-910-11</cap 	PACITOR> BLECT BLECT BLECT BLECT	22MF 470MF 47MF	20% 20% 20%	50 V 16 V 50 V
R383 R384 R385 R387 R388	1-216-115-00 1-216-029-00 1-216-085-00 1-216-049-00 1-216-049-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	560K 5 150 5 33K 5 1K 5 1K 5	% 1/10W % 1/10W % 1/10W % 1/10W % 1/10W		C106 C108 C109 C111 C115	1-126-233-11 1-136-165-00 1-163-133-00 1-124-925-11 1-124-925-11	ELECT FILM CERAMIC CHIP ELECT ELECT	22MF 0.1MF	20% 5% 5% 20% 20%	50V 50V 50V 50V 50V
R389 R390 R391 R392 R393	1-216-101-00 1-216-033-00 1-216-023-00 1-216-019-00 1-216-019-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	150K 5 220 5 82 5 56 5 56 5	% 1/10W % 1/10W % 1/10W % 1/10W % 1/10W		C127 C128 C129 C138 C171	1-124-122-11 1-124-910-11 1-124-910-11 1-136-165-00 1-163-005-11	ELECT ELECT ELECT FILM CERAMIC CHIP	100MF 47MF 47MF 0.1MF	20% 20% 20% 20% 10%	50V 50V 50V 50V 50V
R394 R395 R396 R398	I-216-019-00 I-216-214-00 I-216-041-00 I-216-081-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	56 5 4.7K 5 470 5 22K 5	% 1/10W % 1/8W % 1/10W % 1/10W		C172 C177 C177	1-163-005-11 1-163-005-11 1-102-074-00 1-101-004-00	CERAMIC CHIP CERAMIC	470PF 0.001MF 0.01MF	10%	50 V 50 V 50 V



REF. NO. PART NO.

DESCRIPTION

REMARK | REF. NO. PART NO.

DESCRIPTION

REMARK

The components identified by shading and mark 🛕 are criti-

Replace only with part number

cal for safety.

specified.

	17.5	515	(1	0	11.
٠	l r	BL	JU.	U.	N٠

VIF101 1-466 154-21 IF BLOCK (IFG-389S)

*A-1638-004-A	1	C	BOARD,	COMPLETE

*1-508 765-00 PIN, CONNECTOR (5MM PITCH) 3P *1-568-878-51 PIN, CONNECTOR 3P *1-568-881-51 PIN, CONNECTOR 6P *4-379-160-01 COVER (REAR LID), CV *4-379-167-01 COVER (MAIN), CV

<CONNECTOR>

C71 *1-506-371-00 PIN, CONNECTOR 2P

<CAPACITOR>

C703	1-102-980-00	CERAMIC	270PF	5%	50 V
C704	1-102-116-00	CERAMIC	680PF	10%	50 V
C705	1-102-978-00	CERAMIC	220PF	5%	50 V
C706	1-102-116-00	CERAMIC	680PF	10%	50 V
C707	1-162-116-00	CERAMIC	680PF	10%	2K V
C708 C709 C710 C711 C712	1-162-114-00 1-102-116-00 1-123-947-00 1-101-880-00 1-102-980-00	CERAMIC CERAMIC ELECT CERAMIC CERAMIC	0.0047MF 680PF 10MF 47PF 270PF	10% 20% 5% 5%	2KV 50V 250V 50V 50V
C714	1-124-360-00	ELECT	1000MF	20%	16V
C716	1-162-622-11	CERAMIC	330PF	10%	400V
C717	1-102-114-00	CERAMIC	470PF	10%	50V
C718	1-102-114-00	CHRAMIC	470PF	10%	50V
C719	1-102-114-00	CERAMIC	470PF	10%	50V

<D100E>

D701 D702 D703 D704 D705	8-719-929-16 8-719-911-19 8-719-911-19 8-719-911-19 8-719-911-19	DIODE DIODE DIODE DIODE	HZS9.1NB3 1SS119 1SS119 1SS119 1SS119
D706 D707 D708 D709 D710	8-719-911-19 8-719-911-19 8-719-911-19 8-719-911-19 8-719-911-19	DIODE DIODE DIODE DIODE	1SS119 1SS119 1SS119 1SS119 1SS119
0711	9-710-300-33	DIODE	DIL-ZAM

D711 8-719-300-33 DIODE RU-3AM D713 8-719-911-19 DIODE 1SS119

<JACK>

J701 1-526-990-11 SOCKET, PICTURE TUBE

<001L>

L704 1-410-878-11 INDUCTOR 33UH

<TRANSISTOR>

Q702	8-729-119-78	TRANSISTOR	2SC2785-HFE
Q703	8-729-906-70	TRANSISTOR	BF871
Q704	8-729-200-17	TRANSISTOR	2SA1091-0
9705	8-729-119-78	TRANSISTOR	2SC2785-HFE

<10	>																																																		
10103 8-759 979 62	10 PUF8574																																																		
<c6< th=""><th>IL)×</th><th></th><th></th></c6<>	IL)×																																																		
L100	INDUCTOR INDUCTOR INDUCTOR INDUCTOR	0.56MMH 3.3UH 22UH 1UH																																																	
<tr <="" td=""><td>ANSISTOR></td><td></td><td></td></tr> <tr><th>Q113 8-729-271-22 Q114 8-729-271-22 Q115 8-729-271-22 Q116 8-729-271-22 Q125 8-729-900-89</th><th>TRANSISTOR 2S TRANSISTOR 2S TRANSISTOR 2S TRANSISTOR 2S TRANSISTOR DT</th><th>C2712-G C2712-G C2712-G</th><th></th></tr> <tr><th>0126 8-729-901-06 0181 8-729-119-78</th><th>TRANSISTOR DT TRANSISTOR 2S</th><th></th><th></th></tr> <tr><th><res< th=""><th>SISTOR'S</th><th></th><th></th></res<></th></tr> <tr><th>JR252 1-216-296-00 JR253 1-216-296-00 JR255 1-216-296-00 JR256 1-216-296-00 JR257 1-216-296-00</th><th>METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE</th><th>0 5% 0 5% 0 5% 0 5% 0 5%</th><th>1/8W 1/8W 1/8W 1/8W 1/8W</th></tr> <tr><td>JR258 1-216-296-00 R101 1-216-025-00 R105 1-216-079-00 R107 1-216-081-00 R108 1-216-079 00</td><td>METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE</td><td>0 5% 100 5% 18K 5% 22K 5% 18K 5%</td><td>1/8W 1/10W 1/10W 1/10W 1/10W</td></tr> <tr><td>RIIO 1-249-429-11 RIII 1-216-061-00 RII6 1-216-023-00 RII8 1-216-085-00 RI28 1-216-027-00</td><td>CARBON METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE</td><td>10K 5% 3.3K 5% 82 5% 33K 5% 120 5%</td><td>1/4W 1/10W 1/10W 1/10W 1/10W</td></tr> <tr><td>R129</td><td>METAL GLAZE METAL GLAZE METAL GLAZE CARBON CARBON</td><td>2.2K 5% 2.2K 5% 1K 5% 220 5% 220 5%</td><td>1/10W 1/10W 1/10W 1/4W 1/4W</td></tr> <tr><td>R161 1-216-089-00 R162 1-216-095-00 R163 1-216-095-00 R164 1-216-075-00 R165 1-216-075-00</td><td>METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE</td><td>47K 5% 82K 5% 82K 5% 12K 5% 12K 5%</td><td>1/10W 1/10W 1/10W 1/10W 1/10W</td></tr> <tr><th>R167 1-216-059-00 R168 1-216-089-00 R169 1-216-059-00 R181 1-216-049-00 R182 1-216-065-00</th><th>METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE</th><th>2.7K 5% 47K 5% 2.7K 5% 1K 5% 4.7K 5%</th><th>1/10W 1/10W 1/10W 1/10W 1/10W</th></tr> <tr><td>R193 1-216-073-00 R194 1-216-017-00 R195 1-216-017-00 R196 1-216-113-00</td><td>METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE</td><td>10K 5% 47 5% 47 5% 470K 5%</td><td>1/10W 1/10W 1/10W 1/10W</td></tr> <tr><th><tun< th=""><th>ER></th><th></th><th></th></tun<></th></tr> <tr><td>TU10 (A. 1-465-301-11</td><td>TUNER, ET (UV-</td><td>816(PLL))</td><td></td></tr>	ANSISTOR>			Q113 8-729-271-22 Q114 8-729-271-22 Q115 8-729-271-22 Q116 8-729-271-22 Q125 8-729-900-89	TRANSISTOR 2S TRANSISTOR 2S TRANSISTOR 2S TRANSISTOR 2S TRANSISTOR DT	C2712-G C2712-G C2 712- G		0126 8-729-901-06 0181 8-729-119-78	TRANSISTOR DT TRANSISTOR 2S			<res< th=""><th>SISTOR'S</th><th></th><th></th></res<>	SISTOR'S			JR252 1-216-296-00 JR253 1-216-296-00 JR255 1-216-296-00 JR256 1-216-296-00 JR257 1-216-296-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 5% 0 5% 0 5% 0 5% 0 5%	1/8W 1/8W 1/8W 1/8W 1/8W	JR258 1-216-296-00 R101 1-216-025-00 R105 1-216-079-00 R107 1-216-081-00 R108 1-216-079 00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 5% 100 5% 18K 5% 22K 5% 18K 5%	1/8W 1/10W 1/10W 1/10W 1/10W	RIIO 1-249-429-11 RIII 1-216-061-00 RII6 1-216-023-00 RII8 1-216-085-00 RI28 1-216-027-00	CARBON METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	10K 5% 3.3K 5% 82 5% 33K 5% 120 5%	1/4W 1/10W 1/10W 1/10W 1/10W	R129	METAL GLAZE METAL GLAZE METAL GLAZE CARBON CARBON	2.2K 5% 2.2K 5% 1K 5% 220 5% 220 5%	1/10W 1/10W 1/10W 1/4W 1/4W	R161 1-216-089-00 R162 1-216-095-00 R163 1-216-095-00 R164 1-216-075-00 R165 1-216-075-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	47K 5% 82K 5% 82K 5% 12K 5% 12K 5%	1/10W 1/10W 1/10W 1/10W 1/10W	R167 1-216-059-00 R168 1-216-089-00 R169 1-216-059-00 R181 1-216-049-00 R182 1-216-065-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	2.7K 5% 47K 5% 2.7K 5% 1K 5% 4.7K 5%	1/10W 1/10W 1/10W 1/10W 1/10W	R193 1-216-073-00 R194 1-216-017-00 R195 1-216-017-00 R196 1-216-113-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	10K 5% 47 5% 47 5% 470K 5%	1/10W 1/10W 1/10W 1/10W	<tun< th=""><th>ER></th><th></th><th></th></tun<>	ER>			TU10 (A. 1-465-301-11	TUNER, ET (UV-	816(PLL))	
ANSISTOR>																																																			
Q113 8-729-271-22 Q114 8-729-271-22 Q115 8-729-271-22 Q116 8-729-271-22 Q125 8-729-900-89	TRANSISTOR 2S TRANSISTOR 2S TRANSISTOR 2S TRANSISTOR 2S TRANSISTOR DT	C2712-G C2712-G C2 712- G																																																	
0126 8-729-901-06 0181 8-729-119-78	TRANSISTOR DT TRANSISTOR 2S																																																		
<res< th=""><th>SISTOR'S</th><th></th><th></th></res<>	SISTOR'S																																																		
JR252 1-216-296-00 JR253 1-216-296-00 JR255 1-216-296-00 JR256 1-216-296-00 JR257 1-216-296-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 5% 0 5% 0 5% 0 5% 0 5%	1/8W 1/8W 1/8W 1/8W 1/8W																																																
JR258 1-216-296-00 R101 1-216-025-00 R105 1-216-079-00 R107 1-216-081-00 R108 1-216-079 00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 5% 100 5% 18K 5% 22K 5% 18K 5%	1/8W 1/10W 1/10W 1/10W 1/10W																																																
RIIO 1-249-429-11 RIII 1-216-061-00 RII6 1-216-023-00 RII8 1-216-085-00 RI28 1-216-027-00	CARBON METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	10K 5% 3.3K 5% 82 5% 33K 5% 120 5%	1/4W 1/10W 1/10W 1/10W 1/10W																																																
R129	METAL GLAZE METAL GLAZE METAL GLAZE CARBON CARBON	2.2K 5% 2.2K 5% 1K 5% 220 5% 220 5%	1/10W 1/10W 1/10W 1/4W 1/4W																																																
R161 1-216-089-00 R162 1-216-095-00 R163 1-216-095-00 R164 1-216-075-00 R165 1-216-075-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	47K 5% 82K 5% 82K 5% 12K 5% 12K 5%	1/10W 1/10W 1/10W 1/10W 1/10W																																																
R167 1-216-059-00 R168 1-216-089-00 R169 1-216-059-00 R181 1-216-049-00 R182 1-216-065-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	2.7K 5% 47K 5% 2.7K 5% 1K 5% 4.7K 5%	1/10W 1/10W 1/10W 1/10W 1/10W																																																
R193 1-216-073-00 R194 1-216-017-00 R195 1-216-017-00 R196 1-216-113-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	10K 5% 47 5% 47 5% 470K 5%	1/10W 1/10W 1/10W 1/10W																																																
<tun< th=""><th>ER></th><th></th><th></th></tun<>	ER>																																																		
TU10 (A. 1-465-301-11	TUNER, ET (UV-	816(PLL))																																																	





	al .									L	
	REF.NO. PART NO.	market car at			REMARK	REF.NO.	PART NO.	DESCRIPTION			REMARI
	Q706 8-729-906-70 Q707 8-729-200-17 Q708 8-729-119-78 Q709 8-729-906-70 Q710 8-729-200-17	TRANSISTOR 2SC TRANSISTOR BF8	371 1091-0 2785-HFE 171 11091-0				4-200-001-01 *4-341-751-01 *4-341-752-01 *4-368-683-01	HOLDER, IC EYELET EYELET SPRING			
		SISTOR>						ACITOR>			
	R704 1-216-486-00 R705 1-202-824-00 R706 1-249-409-11 R707 1-249-412-11 R708 1-249-401-11	SOLID CARBON CARBON	8.2K 5% 3.3K 10% 220 5% 390 5% 47 5%	3W 1/2W 1/4W 1/4W 1/4W		C002 C003 C004 C005 C006	1-163-009-11 1-123-875-11 1-124-120-11 1-124-791-11 1-163-125-00	ELECT ELECT ELECT CERAMIC CHIP	10MF 220MF 1MF 220PF	10% 20% 20% 20% 5%	50V 50V 16V 50V 50V
	R709 1-202-844-00 R710 1-215-465-00 R711 1-249-426-11 R712 1-249-417-11 R713 1-215-471-00	SOLID METAL CARBON CARBON	330K 10% 68K 1% 5.6K 5% 1K 5% 120K 1%	1/2W 1/6W 1/4W 1/4W 1/6W		C007 C008 C009 C010 C011	1-163-125-00 1-163-109-00 1-163-109-00 1-124-120-11 1-164-232-11	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP ELECT CERAMIC CHIP	220MF	5% 5% 5% 20%	50V 50V 50V 16V 50V
	R714 1-216-486-00 R715 1-202-824-00 R716 1-249-409-11 R717 1-249-415-11 R718 1-202-814-11	SOLID CARBON CARBON	8.2K 5% 3.3K 10% 220 5% 680 5% 33K 10%	3W 1/2W 1/4W 1/4W 1/2W	F	C012 C013 C014 C015 C016	1-123-875-11 1-106-220-00 1-106-220-00 1-124-902-00 1-163-121-00	MYLAR MYLAR ELECT CERAMIC CHIP		20% 10% 10% 20% 5%	50 V 100 V 100 V 50 V 50 V
	R719 1-249-401-11 R720 1-249-423-11 R721 1-202-842-11 R722 1-202-848-00 R723 1-249-417-11	CARBON CARBON SOLID SOLID	47 5% 3.3K 5% 220K 10% 680K 10% 1K 5%	1/4W 1/4W 1/2W 1/2W 1/4W		C017 C018 C019 C020 C021	1-106-220-00 1-163-127-00 1-106-383-00 1-124-917-11 1-163-117-00	CERAMIC CHIP	0.047MF 33MF	10% 5% 10% 20% 5%	100V 50V 100V 50V 50V
	R724 1-202-846-00 R725 1-202-838-00 R726 1-202-824-00 R727 1-249-409-11 R728 1-216-347-11	SOLID SOLID CARBON	470K 10% 100K 10% 3.3K 10% 220 5% 0.68 5%	1/2W 1/2W 1/2W 1/4W 1W	F	C022 C023 C024 C025 C027	1-164-232-11 1-163-117-00 1-163-117-00 1-163-117-00 1-124-910-11	CERAMIC CHIP CERAMIC CHIP	100PF 100PF	5% 5% 5% 20%	50V 50V 50V 50V 50V
	R729 1-249-416-11 R730 1-249-401-11 R731 1-249-423-11 R732 1-249-415-11 R733 1-249-415-11	CARBON CARBON CARBON CARBON	820 5% 47 5% 3.3K 5% 680 5% 680 5%	1/4W 1/4W 1/4W 1/4W 1/4W		C029 C030 C031 C032 C251	1-163-081-00 1-163-081-00 1-163-081-00 1-163-081-00 1-124-791-11	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	0.22MF 0.22MF	20%	25V 25V 25V 25V 50V
	R734 1-249-405-11 R735 1-215-493-00 R736 1-216-486-00 R737 1-215-491-00 R739 1-249-417-11	CARBON METAL METAL OXIDE METAL	100 5% 1M 1% 8.2K 5% 820K 1% 1K 5%	1/4W 1/6W	F	C252 C253 C254 C255 C261	1-126-233-11 1-163-009-11 1-106-220-00 1-124-636-00 1-124-791-11	ELECT CERAMIC CHIP MYLAR ELECT ELECT	22MF 0.001MF 0.1MF 3300MF 1MF	20% 10% 10% 20% 20%	50V 50V 100V 25V 50V
	<var RV701 1-230-641-11</var 	RIABLE RESISTOR>	L GLAZE 2.2	м		C262 C263 C264 C265 C501	1-126-233-11 1-163-009-11 1-106-220-00 1-124-564-11 1-124-927-11	ELECT CERAMIC CHIP MYLAR ELECT ELECT	22MF 0.001MF 0.1MF 4700MF 4.7MF	20% 10% 10% 20% 20%	50V 50V 100V 25V 50V
	RV702A. 1-230-619-11 RV703		ON 2200 ON 2200		1	C502 C503 C504 C505 C506	1-124-927-11 1-106-371-00 1-163-121-00 1-108-794-11 1-106-375-12	ELECT MYLAR CERAMIC CHIP MYLAR MYLAR	4.7MF 0.015MF 150PF 0.0015MF 0.022MF	20% 10% 5% 5% 10%	50V 400V 50V 50V 250V
	*1-508-765-00 *1-508-786-00 *1-560-290-00	PIN, CONNECTOR PLUG, CONNECTOR	*** (5MM PITCH (5MM PITCH) R (2.5MM PI) 2P TCH)	1 1 1 1 1 1 1 1 1	C507 C508 C509 C510 C511	1-130-783-00 1-106-375-12 1-106-220-00 1-161-959-00 1-108-620-11	MYLAR MYLAR MYLAR CERAMIC MYLAR	0.33MF 0.022MF 0.1MF 22PF 0.0033MF	10% 10% 10% 10% 10%	100V 250V 100V 500V 100V
*1-565-394-11 PIN, BOARD TO BOARD CONNECTOR *1-566-367-11 CONNECTOR, HINGE (RECEPTACLE) *1-568-106-11 PIN, CONNECTOR 4P *1-568-536-11 PLUG (MINIATURE DY) 6P *1-568-878-51 PIN, CONNECTOR 3P					 1 1 1 4 3 8 8	C512 C513 C514 C515 C516	1-106-220-00 1-163-125-00 1-106-228-00 1-124-791-11 1-108-614-11	MYLAR CERAMIC CHIP MYLAR ELECT MYLAR	0.1MF 220PF 0.22MF 1MF 0.001MF	10% 5% 10% 20% 10%	100V 50V 100V 50V 100V
	*1-568-881-51 *1-568-882-51	PIN, CONNECTOR PIN, CONNECTOR	6P) 1 1 2 2	C517 C518	1-124-252-00	ELECT ELECT	0.33MF 0.47MF	20% 20%	50 V 50 V




REF.NO	. PART NO.	DESCRIPTION	V		REMARK	REF.NO	. PART NO.	DESCRIPTION	REMARK
C519 C520 C521 C522 C523	1-136-173-00 1-164-161-11 1-106-220-00 1-124-122-11 1-108-614-11	CERAMIC CHIE MYLAR ELECT	0.47MF 0.0022MF 0.1MF 100MF 0.001MF	5% 10% 10% 20% 10%	50 V 50 V 100 V 50 V 100 V	C822 C823	1-163-005-11 1-106-359-00 1-102-212-00	CERAMIC CHIP 470PF 11 MYLAR 0.0047MF 11	0% 2KV 0% 50V 0% 400V 0% 500V 0% 250V
C524 C525 C526 C527 C531	1-108-798-11 1-163-117-00 1-163-101-00 1-106-220-00 1-124-190-00	CERAMIC CHIE CERAMIC CHIE MYLAR	0.0033MF 2 100PF 2 22PF 0.1MF 680MF	5% 5% 5% 10% 10%	50V 50V 50V 100V 25V	!	1-106-375-12 1-136-518-11 1-136-519-11 1-164-322-51 1-164-322-51	FILM 0.47MF 2/ CERAMIC 0.0047MF 2/ CERAMIC 0.0047MF 2/	0% 300V 0% 300V 0% 400V 0% 400V
C532 C533 C534 C536 C537	1-124-514-11 1-106-216-00 1-124-120-11 1-131-365-00 1-124-791-11	BLECT MYLAR BLECT TANTALUM BLECT	100MF 0.068MF 220MF 10MF IMF	20% 10% 20% 10% 20%	50V 100V 16V 16V 50V	116062	L 1-161-964-61	CERAMIC 0.0047MF 21 CERAMIC 0.0047MR	0% 400V
C538 C539 C540 C592 C593	1-108-614-11 1-163-129-00 1-163-009-11 1-124-122-11 1-163-129-00	MYLAR CERAMIC CHIE CERAMIC CHIE BLECT	0.001MF 330PF 0.001MF	10% 5% 10% 20% 5%	100V 50V 50V 50V 50V	CF001 CF501	1-577-364-11	VIBRATOR, CERAMIC OSCILLATOR, CERAMIC	
C603 Z	N 1-161-964-61 N 1-161-964-61 N 1-161-964-61 N 1-125-318-11 1-124-510-11	CERAMIC ELECT (BLOCK)	0.0047MF	20% 20%	250V 250V 250V 400V 35V	D001 D002 D003 D004 D005	8-719-911-19 8-719-929-03 8-719-911-19 8-719-911-19	DIODE 188119 DIODE HZ86.8NB3	
C606 C607 C608 C611 C612	1-163-137-00 1-130-834-00 1-124-927-11 1-124-910-11 1-108-614-11	CERAMIC CHIP MYLAR BLECT BLECT MYLAR	680PF 1MF 4.7MF 47MF 0.001MF	5% 10% 20% 20% 10%	50V 63V 50V 50V 100V	D006 D007 D009 D010 D011	8-719-929-71 8-719-911-19 8-719-109-89 8-719-120-78 8-719-120-78	DIODE H7C33ND1	
C613 C614 C615 C616 C617	1-136-539-11 1-102-030-00 1-124-557-11 1-102-030-00 1-124-122-11	CERAMIC ELECT CERAMIC	0.0022MF 330PF 1000MF 330PF 100MF	3% 10% 20% 10% 20%	2KV 500V 25V 500V 50V	D271 D272 D501 D504 D506	8-719-110-36 8-719-911-19 8-719-911-19 8-719-911-55 8-719-800-76	DIODE RD13ES-B2 DIODE 1SS119 DIODE 1SS119	
C618 C619 C620 C621 C622	1-162-115-00 1-124-556-11 1-136-173-00 1-124-347-00 1-124-556-11	ELECT Film Elect	330PF 2200MF 0.47MF 100MF 2200MF	10% 20% 5% 20% 20%	2KV 16V 50V 160V 16V	D508 D509 D511 D512 D513	8-719-911-19 8-719-911-19 8-719-911-55 8-719-911-55	DIODE 1SS119 DIODE 1SS119 DIODE UO5G	
C623 C624 C625 C626 C627	1-124-910-11 1-124-122-11 1-124-360-00 1-123-875-11 1-163-009-11	ELECT	47MF 100MF 1000MF 10MF 0.001MF	20% 20% 20% 20% 10%	50V 50V 16V 50V 50V	D601 A		DIODE KBU4JL-6088	
C631 C632 C633 C801 C802	1-124-927-11 1-163-009-11 1-163-117-00 1-126-105-11 1-102-030-00	ELECT CERAMIC CHIP CERAMIC CHIP ELECT CERAMIC		20% 10% 5% 20% 10%	50V 50V 50V 35V 500V	D606 D607 D608 D609 D610	8-719-300-33 8-719-300-33 8-719-300-33 8-719-929-71 8-719-300-59	DIODE RU-3AM DIODE RU-3AM DIODE RU-3AM DIODE HZS33NB1 DIODE CTU-12S	
C804 C805 C806 C807 C810	1-123-948-00 1-162-114-00 1-106-220-00 1-106-395-00 1-123-024-21	ELECT CERAMIC MYLAR MYLAR ELECT	22MF 0.0047MF 0.1MF 0.15MF 33MF	20% 10% 10%	250V 2KV 100V 200V 160V	D611 D612 D613 D614 D616	8-719-900-26 8-719-300-59 8-719-979-85 8-719-979-85 8-719-120-78	DIODE ERD29-08J DIODE CTU-12S DIODE EGP20G DIODE EGP20G DIODE RD6.2ES-L3	
C815	1-136-113-00 1-124-634-11 1-102-212-00 .1-161-731-11 1-136-111-00	FILM ELECT CERAMIC CERAMIC FILM	2MF 1MF 820PF 0.001MF	5% 20% 10% 10%	200V 250V 500V 2KV 200V	D617 D618 D619 D620 D621	8-719-911-19 8-719-109-89 8-719-929-71 8-719-800-76 8-719-929-71	DIODE 1SS119 DIODE RD5.6ES-B2 DIODE HZS33NB1 DIODE 1SS226 DIODE HZS33NB1	
C817 C818 C819 A C820	1-136-565-11 1-136-759-11 1-161-731-11 1-106-218-00	FILM FILM CBRAMIC MYLAR	0.015MF 0.039MF 0.001MF 0.0082MF	3% 10% 10% 10%	1.4KV 630V 2KV 400V	D622 D623 D624	8-719-911-19 8-719-911-19 8-719-911-19	DIODE 1SS119 DIODE 1SS119	

REF.NO.	PART NO.		REMARK	REF.NO.	PART NO.	DESCRIPTION		
D630 D801 D802 D803 D804	8-719-300-33 8-719-300-33 8-719-300-65	DIODE RD15ES-B1 DIODE RU-3AM		Q002 Q003 Q004 Q005	8-729-901-06 8-729-216-22 8-729-216-22 8-729-901-01	TRANSISTOR DT TRANSISTOR 2S TRANSISTOR 2S TRANSISTOR DT	SA1162-G SA1162-G CC144EK	
D805 D806 D807 D808	8-719-911-55 8-719-945-80 8-719-945-80 8-719-900-26	DIODE U05G DIODE ERC06-15S DIODE ERC06-15S DIODE ERD29-08J		Q006 Q007 Q008 Q009 Q251	8-729-901-01 8-729-271-22 8-729-271-22 8-729-271-22 8-729-271-22	TRANSISTOR DI TRANSISTOR 2S TRANSISTOR 2S TRANSISTOR 2S TRANSISTOR 2S	SC2712-G SC2712-G SC2712-G	
	C			Q261 Q271 Q502	8-729-271-22 8-729-271-22 8-729-216-22	TRANSISTOR 25 TRANSISTOR 25 TRANSISTOR 25	SC2712-G	
I C001 I C002 I C003	8-759-501-66 8-752-332-82 8-759-945-58	IC SDA2083-B012 IC CXD1050A-09P IC RC4558P		Q505 Q506	8-729 140-96 8-729-140-97 8-729-216-22	TRANSISTOR 29 TRANSISTOR 29 TRANSISTOR 29	SB734-34	
I C005 I C251	8-759-748-30 8-759-988-94 4-201-023-01 4-812-134-00	IC SDA2083-B012 IC CXD1050A-09P IC RC4558P IC SDA2546 IC TDA2050 SPACER, INSULATING; IC251 RIVET NYLON, 3.5; IC25! IC TDA2050		0598 0601 0602 0603	8-729-216-22 8-729-111-67	TRANSISTOR 25	SA1162-G SB1094-L	
I C261	8-759-988-94 4-201-023-01 4-812-134-00	IC TDA2050 SPACER, INSULATING; IC261 RIVET NYLON, 3.5; IC261		Q604 Q605 Q606	8-729-216-22 8-729-271-22 8-729-271-22	TRANSISTOR 25 TRANSISTOR 25 TRANSISTOR 25	SA1162-G SC2712-G SC2712-G	
10501 10502	8-759-970-73 8-759-944-57 8-759-988-95	IC TEA2028B IC TDA8170 IC TEA2260		Q607 Q608	8-729-920-92 8-729-271-22	TRANSISTOR 25	SD2096-EF SC2712-G	
1 C604 1 C608	8-759-144-84 8-759-037-26	IC UPC24M05HF IC TYA7812CT		Q609 Q801 Q804 Q805	8-729-320-62 8-729-271-22 8-729-304-50 8-729-119-80	TRANSISTOR 2: TRANSISTOR 2: TRANSISTOR 2: TRANSISTOR 2:	SD789-34 SC2712-G SD1941-06 SC2688-LK	
1.001	<00I	L>			< RFS	ISTOR>		
L501 L501 L601 L602 L603	1-408-414-00 1-408-225-00 *1-420-872-00 1-410-396-41 1-410-396-41	SPACER, INSULATING; IC251 RIVET NYLON, 3.5; IC25! 1C TDA2050 SPACER, INSULATING; IC261 RIVET NYLON, 3.5; IC261 IC TEA2028B IC TDA8170 IC TEA2260 IC UPC24M05HF IC TYA7812CT L> INDUCTOR 27UH INDUCTOR 3.3UH COIL, AIR CORE FERRITE BEAD INDUCTOR FERRITE BEAD INDUCTOR INDUCTOR 47UH COIL (HORIZONTAL CHOKE) 25UH INDUCTOR 47UH COIL, DUST CORE INDUCTOR 4.7MH COIL, HORIZONTAL LINEARITY COIL, HORIZONTAL LINEARITY COIL, DRAM CORE (CDI) COIL, AIR CORE PMC		R001 R002 R003 R004	1-216-041-00 1-216-041-00 1-249-417-11 1-216-049-00	METAL GLAZE METAL GLAZE CARBON METAL GLAZE	470 5 470 5 1K 5	% 1/10W
L604 L605 L606 L607 L803	1-410-671-31 1-459-585-11 1-421-013-00 1-410-671-31 1-459-104-00	INDUCTOR 47UH COIL (WITH CORE) (DRUM TYPE) COIL (HORIZONTAL CHOKE) 25UH INDUCTOR 47UH COIL, DUST CORE		R005 R006 R007 R008	1-249-417-11 1-216-073-00 1-216-065-00 1-216-073-00 1-216-073-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	10K 5 4.7K 5 10K 5	% 1/10W % 1/10W % 1/10W
L804 L805 A	1-408-239-00 1-459-755-12	INDUCTOR 4.7MMH COIL, HORIZONTAL LINEARITY		R010	1-216-041-00	METAL GLAZE	10K 5	
L806 L809 L810 A	1-459-111-00 *1-420-872-00 .1-421-982-12	COIL, DRAM CORE (CDI) COIL, AIR CORE PMC	1.5%	R011 R013 R014 R015 R016	1-216-065-00 1-216-073-00 1-216-071-00 1-216-061-00 1-216-085-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	3, 10, 1	% 1/10W % 1/10W
e de la companione de l		NSFORMER>		R017	1-216-748-11	METAL GLAZE	39K 5	1/10W 1/10W
LF1603 T601	ሉ. 1-421-866-12 ሉ. 1-421-776-11 ሉ. 1-421-592-21 ሉ. 1-450-038-11 ሉ. 1-424-277-11	LFT LFT TRANSFORMER, FERRITE S.R.T TRANSFORMER, TRIGGER PULSE	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	R018 R019 R020 R021	1-216-095-00 1-216-049-00 1-216-049-00 1-216-065-00	METAL GLAZE METAL GLAZE METAL GLAZE	1K 5 1K 5 4.7K 5	1/10W 1/10W 1/10W
T801	A. 1-437-090-21		11.74	R022 R023 R024 R025	1-216-065-00 1-216-035-00 1-216-049-00 1-216-025-00 1-249-417-11	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE CARBON	1K 5	1/10W 1/10W 5% 1/10W 5% 1/10W 5% 1/4W
		LINK>		R026	1-216-025-00	METAL GLAZE		
PS601 <u>A</u> PS602 <u>A</u> PS603 <u>A</u>	1-532-984-91 1-532-984-91 1-532-679-91	LINK, IC (ICP-N50) 2A LINK, IC (ICP-N50) 2A LINK, IC (ICP-N15) 0.6A		R028	1-216-025-00 1-216-073-00 1-216-073-00 1-216-081-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	10K -	5% 1/10W 5% 1/10W 5% 1/10W 5% 1/10W 1/10W
		NSISTOR>		R032 R033	1-216-073-00 1-216-073-00	METAL GLAZE	10K	5% 1/10W 5% 1/10W
2001	8-729-901-01	TRANSISTOR DTC144EK		1 RO34	1-216-077-00	METAL GLAZE	15K 5	5% 1/10W



	. PART NO.	DESCRIPTION				REMARK	REF.NO.	PART NO.	DESCRIPTION			REMARK
R035 R036 R037 R038 R039	1-216-081-00 216-079-00 1-216-065-00 1-216-059-00 1-216-081-00	METAL GLAZE	22K 18K 4.7K 2.7K 22K	5% 5%	1/10W 1/10W 1/10W 1/10W		R273 R500 R501 R502 R503	1 216 973 00 1 216 115 00 1 216 041 00 1 216 033 00 1 216 035 00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	10K 560K 470 220 270	5% 5%% 55% 55% 55% 55% 55% 55% 55% 55%	1/10W 1/10W 1/10W 1/10W 1/10W
R040 R041 R042 R043 R044	1-216-077-00 1-216-073-00 1-216-049-00 1-216-041-00 1-216-097-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	15K 10K 1 K 470 100K	5%%%% 5%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%	1/10W 1/10W 1/10W 1/10W 1/10W		R504 R505 R506 R509 R510	1-249-420-11 1-216-077-00 1-216-071-00 1-216-063-00 1-216-067-00	CARBON METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	1.8K 15K 8.2K 3.9K	5% 5% 5%	1/4W 1/10W 1/10W 1/10W 1/10W
R045 R046 R047 R048 R049	1-216-061-00 1-216-085-00 1-216-073-00 1-216-073-00 1-216-073-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	33K 10K 10K 10K	5%% 5%% 5%% 5%% 5%%	1/10W 1/10W 1/10W 1/10W 1/10W		R514 R515 R517 R518 R519	1-216-033-00 1-216-061-00 1-216-073-00 1-216-089-00 1-216-081-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	220	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W
R050 R051 R052 R053 R054	1-216-067-00 1-216-041-00 1-216-049-00 1-216-049-00 1-216-049-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	470 1 K 1 K 1 K	5%	1/10W 1/10W 1/10W 1/10W 1/10W		R520 R521 R522 R523 R524 R525	1-216-037-00 1-216-025-00 1-249-441-11 1-216-049-00 1-216-057-00	METAL GLAZE CARBON METAL GLAZE METAL GLAZE	100 100K 1K 2.2K	5% 5% 5%	1/10W 1/10W 1/4W 1/10W 1/10W
R055 R056 R057 R058 R059	1-216-037-00 1-216-025-00 1-216-033-00 1-216-063-00 1-249-417-11	METAL GLAZE METAL GLAZE METAL GLAZE CARBON	100 220 3.9K 1K		1/10W 1/10W 1/10W 1/10W 1/4W		R526 R527 R528 R529	1-216-049-00 1-249-409-11 1-216-077-00 1-216-031-00 1-216-069-00	METAL GLAZE	220 15K 180 6.8K 1.2	5% 5% 5%	1/10W 1/4W F 1/10W 1/10W 1/10W
R060 R061 R062 R063 R064	1-216-049-00 1-249-417-11 1-249-417-11 1-249-429-11 1-249-417-11	CARBON CARBON CARBON	1 K 1 K 1 K 1 O K 1 K	5% 5% 5%	1/10W 1/4W 1/4W 1/4W 1/4W		R534	1-249-448-11 1-216-099-00 1-216-049-00 1-216-295-00 1-216-119-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	120K 1K 0 820K	5% 5% 5%	1/4W F 1/10W 1/10W 1/10W 1/10W
R065 R066 R067 R068 R069	1-249-429-11 1-216-049-00 1-216-049-00 1-249-417-11 1-249-417-11	CARBON		5% 5%	1/4W 1/10W 1/10W 1/4W 1/4W		R535 R536 R537 R538 R539	1-216-101-00 1-216-101-00	METAL GLAZE METAL GLAZE METAL GLAZE	2.2M 2.2M 27K 150K 150K	5% 5%	1/4W 1/10W 1/10W 1/10W 1/10W
R070 R071 R072 R073 R074	1-249-417-11 1-249-417-11 1-249-417-11 1-216-049-00 1-216-065-00	CARBON CARBON METAL GLAZE METAL GLAZE	1K 1K 1K 4.7K	5% 5% 5%	1/4W 1/4W 1/4W 1/10W 1/10W		R540 R541 R542 R543 R544	1-216-013-00 1-216-091-00 1-216-308-00 1-249-451-11 1-247-745-11	METAL GLAZE CARBON CARBON	56K 4.7 2.2 330	5% 5% 5% 5% 5%	1/10W 1/10W 1/10W 1/4W 1/2W
R076 R077 R078 R251	1-216-049-00 1-216-049-00 1-216-065-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	1K 4.7K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R546 R547 R548 R549	1-216-061-00 1-216-349-00 1-216-454-11	METAL GLAZE METAL GLAZE METAL OXIDE METAL OXIDE	3.3K 1 390		1/10W 1/10W 1/10W 1W F 2W F
R252 R253 R254 R255 R256	1-216-039-00 1-216-073-00 1-216-357-00 1-216-073-00 1-216-115-00	METAL GLAZE METAL GLAZE METAL OXIDE METAL GLAZE METAL GLAZE	390 10K 4.7 10K 560K	555555	1/10W 1/10W 1W 1/10W 1/10W	F	R550 R551 R553 R554 R555	1-216-095-00 1-216-129-00 1-216-869-11 1-216-037-00 1-216-129-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	82K 2.2M 1K 330 2.2M	5% 5% 5%	1/10W 1/10W 1W 1/10W 1/10W
R257 R258 R259 R261 R262	1-216-077-00 1-215-869-11 1-216-065-00 1-216-065-00 1-216-039-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	15K 1K 4.7K 4.7K 390	5%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%	1/10W 1W 1 1/10W 1/10W 1/10W	F	R556 R557 R558 R559 R560	1-216-025-00 1-216-065-00 1-216-113-00 1-216-069-00 1-216-037-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	100 4.7K 470K 6.8K 330	5% 5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W
R263 R264 R265 R266 R267	1-216-073-00 1-216-357-00 1-216-073-00 1-216-115-00 1-216-077-00	METAL GLAZE METAL OXIDE METAL GLAZE METAL GLAZE METAL GLAZE	10K 4.7 10K 560K 15K	5%	1/10W 1W F 1/10W 1/10W 1/10W		R591 R592 R593 R594 R597	1-216-047-00 1-216-049-00 1-216-053-00 1-216-071-00 1-216-041-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	820 1K 1.5K 8:2K 470	5% %%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%	1/10W 1/10W 1/10W 1/10W 1/10W
R268 R269 R271 R272	1-215-869-11 1-216-065-00 1-216-045-00 1-216-073-00	METAL OXIDE METAL GLAZE METAL GLAZE METAL GLAZE	1K 4.7K 680 10K	5% 5% 5%	1W F 1/10W 1/10W 1/10W		R598 R600 R601	1-215-900-11 1-249-381-11 1-216-353-00	METAL OXIDE CARBON METAL OXIDE	22K 1 2.2	5% 5% 5%	2W F 1/4W 1W F

The components identified by shæding and mark A are critical for safety.
Replace only with part number specified.



REF.NO. PART NO.	DESCRIPTION	REMARI	REF.NO. PART NO. DESCRIPTION REMARK
R603 1-216-469-11 R604 1-216-025-00 R605 1-216-081-00 R606 1-216-051-00 R607 1-216-065-00	METAL GLAZE 100 METAL GLAZE 22K METAL GLAZE 22K METAL GLAZE 1.2K METAL GLAZE 4.7K	5% 3W F 5% 1/10W 5% 1/10W 5% 1/10W 5% 1/10W	RV501 1-238-013-11 RES, ADJ, CARBON 2.2K RV502 1-238-016-11 RES, ADJ, CARBON 10K RV601 1-238-011-11 RES, ADJ, CARBON 470
R608 A 1-216-488-51 R609	METAL GLAZE 18 CARBON 680K	5% 3W F 5% 1/10W 5% 1/2W 5% 1/10W 5% 1/10W	<spark gap=""> SG801 1-519-422-11 GAP, SPARK <thermistor></thermistor></spark>
R613 1-216-097-00 R614 1-205-758-11 R616 1-216-099-00 R617 1-249-411-11 R618 1-216-431-11	WIREWOUND 100 METAL GLAZE 120K	5% 1/10W 10% 10W F 5% 1/10W 5% 1/4W 5% 1W F	THP601A.1-808-059-31 THERMISTOR, POSITIVE
R619 1-216-073-00 R620 1-216-081-00 R621 1-216-077-00 R622 1-216-073-00 R623 1-216-681-00		5% 1/10W 5% 1/10W 5% 1/10W 5% 1/10W 5% 1/10W	*1-633-409-11 H1 BOARD ********* 1.562-837-11 JACK *1-564-512-11 PLUG, CONNECTOR 9P (KV-C2531D ONLY) *1-568-879-51 PIN, CONNECTOR 4P *1-568-881-51 PIN, CONNECTOR 6P
R624 1-216-067-00 R625 1-215-865-11 R626 1-216-037-00 R628 1 216-001-00 R629 1-216-037-00	METAL OXIDE 220 S METAL GLAZE 330 S METAL GLAZE 10 S	5% I/10W 5% IW F 5% I/10W 5% I/10W 5% I/10W	1-569-473-11 JACK BLOCK, PIN 3P (KV-C2531D ONLY) <resistor></resistor>
R633 !-216-049-00 R634 !-216-430-11 R635 !-216-073-00 R636 !-216-073-00 R643 !-217-189-21	METAL GLAZE 1K METAL OXIDE 390 METAL GLAZE 1OK METAL GLAZE 1OK MIREWOUND 0.12	5% 1/10W 5% 1W F 5% 1/10W 5% 1/10W 5% 2W F	R1651 1 249-413-11 CARBON 470 5% 1/4W R1652 1-249-413-11 CARBON 470 5% 1/4W <switch></switch>
R651 1-216-025-00 R653 1-205-758-11 R802 1-249-443-11 R805 1-249-448-11 R806 1-216-093-00	WIREWOUND 100 1 CARBON 0.47 5 CARBON 1.2 5	5% 1/10W 10% 10W F 5% 1/4W F 5% 1/4W F 5% 1/10W	\$1651 1-571-532-21 SWITCH, TACTIL \$1652 1-571-532-21 SWITCH, TACTIL \$1653 1-571-532-21 SWITCH, TACTIL
R807 1-215-869-11 R809 1-202-821-11 R810 1-202-818-00 R811 1-215-882-00 R812 1-249-494-11	SOLID 1.8K 1 SOLID 1K 1 METAL OXIDE 22 5	5% 1W F 10% 1/2W 10% 1/2W 5% 2W F 5% 1/2W	*1-633-410-11 H2 BOARD ********** *1-568-882-51 PIN, CONNECTOR 7P *4-374-987-01 GUIDE, LIGHT *4-381-686-01 BRACKET (B), LIGHT GUIDE
R815 1 215-884-11 R816 1-215-868-00 R817 1-216-049-00 R820 1-249-403-11 R821 1-247-725-11	CARBON 68 5	5% 2W F 5% 1W F 5% 1/10W 5% 1/4W 5% 1/4W F	<pre></pre>
R822 A 1-217-778-61 R825 I-216-345-11 R826 I-216-097-00 R827 I-216-073-00 R828 I-216-059-00	METAL OXIDE 0.47 5 METAL GLAZE 100K 5 METAL GLAZE 10K 5	5% 1W F 5% 1W F 5% 1/10W 5% 1/10W 5% 1/10W	D1652 8-719-948-31 D10DE LD-201VR *4-387-825-01 HOLDER, LED; D1652 D1654 8-719-948-31 D10DE LD-201VR *4-387-825-01 HOLDER, LED; D1654
R829 1-216-051-00 R831 1-249-451-11 R1601A 1-246-513-75 R1602A 1-244-945-91 R1603A 1-217-328-11	CARBON 2.2 5 CARBON 47K 5 CARBON 1M 5	5% 1/10W 5% 1/4W 5% 1/4W 5% 1/2W 10% 7W F	<1C> IC1651 8-741-138-70 IC BX-1387
R1604A 1-246-513-75 R1605A 1-218-265-91 R5501 1-216-073-00 R5503 1-216-308-00 R5504 1-216-121-00	METAL GLAZE 10K 5 METAL GLAZE 4.7 5	1/4W 2 1W 2 1/10W 3 1/10W 3 1/10W 2 1/10W	<pre></pre>
R5505 1-216-001-00	METAL GLAZE 10 5	5% 1/10W	*A-1651-014-A J1 BOARD, COMPLETE ***********************************
<var< td=""><td>IABLE RESISTOR></td><td></td><td>1-561-534-41 SOCKET 21P *1-564-518-11 PLUG, CONNECTOR 3P</td></var<>	IABLE RESISTOR>		1-561-534-41 SOCKET 21P *1-564-518-11 PLUG, CONNECTOR 3P

REF.NO. PART NO.	DESCRIPTION			REMARK	REF.NO.	PART NO.	DESCRIPTION			REMARK
*1-564-524-11 *j-564-527-11 *1-566-641-11	PLUG, CONNECTO PLUG, CONNECTO CONNECTOR, HEN	DR 91' DR 12P DGE (TAE) 1	8P		C1429 C1430	1 136-017 00 1-163-003-11	CERAMIC CHIP CERAMIC CHIP	0.0047MF 330PF	10%	50V 50V
	PACITUR				C1432 C1433	1 126 529 11 1-124 902-00 1-124-122-11 1-163-009-11	BLECT BLECT BLECT CERAMIC CHIP	100 MF	20% 20% 20% 10%	50 V 50 V 50 V 50 V
C203 1-124-925-11 C205 1-124-927-11 C206 1-124-925-11	ELECT 2 ELECT 4 ELECT 2	2.2MF 1.7MF 1.2MF		50 V 50 V 50 V	C1437	1-163-009-11	CERAMIC CHIP	0.001MF 0.01MF	10%	50 V 400 V
C207 1-124-927-11 C213 1-126-233-11 C214 1-106-363-00	ELECT 2	.7MF 22MF .0068MF	20% 20% 10%	50V 50V 400V	C1440 C1441	1 106 367 00 1-123-875-11 1-123-875-11 1 106 220-00	ELECT ELECT	0.01MF 10MF 10MF 0.1MF	10% 20% 20% 10%	400V 50V 50V 100V
C217 1-106-363-00 C218 1-106-375-12 C219 1-106-375-12	MYLAR O	0.0068MF 0.022MF 0.022MF	10% 10% 10%	400V 250V 250V	C1443 C1444	1 106-220-00 1-124-910-11	MYLAR FLECT	O.IMF 47MF	10%	100V 50V
C220 1:108-620:11 C221 1-108-620:11 C222 1-106-385-00	MYLAR 0	.0033MF .0033MF .056MF	10% 10% 10%	100V 100V 100V	C1446 C1501	1-102-824-00 1-102-824-00 1-124-927-11	ELECT	470PF 470PF 4.7MF	5% 5% 20%	50 V 50 V 50 V
C223	MYLAR O MYLAR O FILM O	.056MF .01MF .47MF	10% 10% 5%	100V 400V 50V	C1502 C1503 C1504	1-124-791-11 1-108-614-11 1-124-910-11 1-106-383-00 1-108-620-11	ELECT MYLAR ELECT	1MF 0.001MF 47MF 0.047MF	20% 10% 20% 10%	50 V 100 V 50 V
C226 1-136-173-00 C227 1-106-375-12 C228 1-106-379-12	MYLAR O	.47MF .022MF	5% 10% 10%	50 V 250V 250V				0.0033MF	10%	100V 100V 50V
C229 1-106-371-00 C230 1-106-371-00			10% 10%	400V 400V	C1511 C1512	1-124-791-11 1-124-791-11 1-124-927-11 1-106-363-00	MYLAR	1MF 1MF 4.7MF 0.0068MF	20% 20% 10%	50 V 50 V 400 V
C231 1-124-902-00 C232 1-123-875-11 C233 1-163-005-11 C234 1-163-005-11	ELECT 1: CERAMIC CHIP 4	.47MF OMF 70PF 70PF	20% 20% 10% 10%	50V 50V 50V		1-163-105-00 1-106-375-12 1-102-117-00			5% 10% 10%	50V 250V 50V
C235 1-163-005-11	CERAMIC CHIP 4	7000	10%	50V		1 102 111 00	obilini o	04011	10%	50.
						< CUN	NECTOR>			
C236 1-163-005-11 C237 1-124-902-00 C238 1-163-125-00 C239 1-126-103-11	CERAMIC CHIP 4' ELECT 0 CERAMIC CHIP 2' ELECT 4'	70PF .47MF 20PF 70MF	10% 20% 5% 20%	50V 50V 50V 16V	CN1401	<con 1-565-838-11</con 	NECTOR> PIN JACK BLOO	CK 2P		
C236 1-163-005-11 C237 1-124-902-00 C238 1-163-125-00 C239 1-126-103-11 C240 1-163-018-00 C241 1-163-018-00	CERAMIC CHIP 4' ELECT 0 CERAMIC CHIP 2: ELECT 4' CERAMIC CHIP 0 CERAMIC CHIP 0	70PF .47MF 20PF 70MF .0056MF	10% 20% 5% 20% 10%	50V 50V 50V 16V 50V		1-565-838-11 <d10< td=""><td>PIN JACK BLOO DES</td><td></td><td></td><td></td></d10<>	PIN JACK BLOO DES			
C236 1-163-005-11 C237 1-124-902-00 C238 1-163-125-00 C239 1-126-103-11 C240 1-163-018-00	CERAMIC CHIP 4' ELECT 0 CERAMIC CHIP 2' CERAMIC CHIP 0	70PF .47MF 20PF 70MF .0056MF	10% 20% 5% 20% 10%	50V 50V 50V 16V 50V	D201 D202 D205 D206	1-565-838-11 <d10 8-719-929-16 8-719-929-16 8-719-929-08 8-719-929-08</d10 	PIN JACK BLOODE DIODE HZS9.11 DIODE HZS9.51 DIODE HZS7.51 DIODE HZS7.51	NB3 NB3 NB3 NB3		
C236 1-163-005-11 C237 1-124-902-00 C238 1-163-125-00 C239 1-126-103-11 C240 1-163-018-00 C241 1-163-033-00 C242 1-163-033-00 C243 1-163-033-00 C244 1-163-033-00 C245 1 163-033-00 C1401 1 123-875-11 C1402 1-126-103-11	CERAMIC CHIP 4' BLECT CERAMIC CHIP 2' BLECT CERAMIC CHIP 0	70PF .47MF 20PF 70MF .0056MF .0026MF .022MF .022MF .022MF .022MF	10% 20% 5% 20% 10% 10%	50V 50V 50V 16V 50V 50V 50V 50V 50V 50V 50V	D201 D202 D205 D206 D1401	1-565-838-11 <010 8-719-929-16 8-719-929-16 8-719-929-08 8-719-929-08 8-719-929-08	DIN JACK BLOODE DIODE HZS9.11 DIODE HZS7.51 DIODE HZS7.51 DIODE HZS7.51 DIODE HZS7.51	NB3 NB3 NB3 NB3 NB3		
C236 l-163-005-11 C237 l-124-902-00 C238 l-163-125-00 C239 l-126-103-11 C240 l-163-018-00 C241 l-163-033-00 C242 l-163-033-00 C243 l-163-033-00 C244 l-163-033-00 C245 l-163-033-00 C1401 l-123-875-11 C1402 l-126-103-11 C1403 l-163-003-11 C1404 l-106-220-00 C1405 l-136-017-00	CERAMIC CHIP 4' BLECT CHIP 2: ELECT 4 CERAMIC CHIP 0 CERAMIC CHIP 3' MYLAR 0 CERAMIC CHIP 0	70PF .47MF 20PF 70MF .0056MF .0024MF .022MF .022MF .022MF .022MF .021MF .021MF .021MF .0047MF	10% 20% 5% 20% 10% 10%	50V 50V 50V 16V 50V 50V 50V 50V 50V 50V 16V 50V	D201 D202 D205 D206 D1401	1-565-838-11 <010 8-719-929-16 8-719-929-16 8-719-929-08 8-719-929-08 8-719-929-08	DIODE HZS9.11 DIODE HZS9.11 DIODE HZS9.15 DIODE HZS7.51 DIODE HZS7.51 DIODE HZS7.51	NB3 NB3 NB3 NB3 NB3 NB3 NB3		
C236	CERAMIC CHIP 4' ELECT 0 CERAMIC CHIP 0' CERAMIC CHIP 0 ELECT 1' ELECT 1' CERAMIC CHIP 3' MYLAR 0 CERAMIC CHIP 0 MYLAR 0. MYLAR 0. ELECT 4' ELECT 1' ELE	70PF .47MF 20PF 70MF .0056MF .0026MF .022MF .022MF .022MF .022MF .021MF .0047MF .1MF .1MF .1MF	10% 20% 5% 20% 10% 10% 20% 20% 10%	50V 50V 50V 50V 50V 50V 50V 50V 50V 50V	D201 D202 D205 D206 D1401 D1404 D1405 D1407 D1408 D1409	1-565-838-11 <pre></pre>	DIODE HZS9.11 DIODE HZS9.11 DIODE HZS9.51 DIODE HZS7.51 DIODE HZS7.51 DIODE HZS7.51 DIODE HZS7.51 DIODE HZS7.51 DIODE HZS9.11 DIODE HZS9.11 DIODE HZS9.11 DIODE HZS9.11	NB3 NB3 NB3 NB3 NB3 NB3 NB3 NB3 NB3 NB3		
C236	CBRAMIC CHIP 4' BLECT CERAMIC CHIP 2' ELECT CERAMIC CHIP 0 CERAMIC CHIP 3' MYLAR 0 CERAMIC CHIP 0 MYLAR 0 ELECT 4' ELECT 1(EL	70PF .47MF 20PF 70MF .0056MF .0024MF .022MF .022MF .022MF .0047MF .1MF .0047MF .1MF .1MF .1MF .0047MF	10% 20% 5% 20% 10% 10% 10% 10% 10% 20% 20% 20% 20% 20% 20% 20% 20%	50V 50V 50V 16V 50V 50V 50V 50V 50V 50V 100V 50V 100V 50V 50V 50V	D201 D202 D205 D206 D1401 D1404 D1405 D1407 D1408 D1409	1-565-838-11 <pre></pre>	DIODE HZS9.11 DIODE HZS9.11 DIODE HZS7.51 DIODE HZS7.51 DIODE HZS7.51 DIODE HZS7.51 DIODE HZS7.51 DIODE HZS7.51 DIODE HZS9.11 DIODE HZS9.11 DIODE HZS9.11	NB3 NB3 NB3 NB3 NB3 NB3 NB3 NB3 NB3 NB3		
C236	CERAMIC CHIP 4' BLECT CERAMIC CHIP 2: BLECT CERAMIC CHIP 0 CERAMIC CHIP 1 CERAMIC CHIP 0 CERAMIC CHIP 1 CERAMIC	70PF .47MF 20PF 70MF .0056MF .0024MF .022MF .022MF .022MF .022MF .0047MF .1MF 70MF .1MF 70MF 00MF 20MF 00MF	10% 20% 5% 20% 10% 10% 20% 20% 20% 20% 20% 20% 20% 20% 20% 2	50V 50V 50V 16V 50V 50V 50V 50V 50V 100V 50V 100V 50V 50V 50V 50V 50V 50V 50V 50V 50V	D201 D202 D205 D206 D1401 D1404 D1405 D1407 D1408 D1410 D1418 D1419 D1420 D1422 D1423	1-565-838-11 <pre></pre>	DIODE HZS9.11 DIODE HZS9.11 DIODE HZS9.11 DIODE HZS7.51 DIODE HZS7.51 DIODE HZS7.51 DIODE HZS7.51 DIODE HZS7.51 DIODE HZS9.11 DIODE HZS9.11 DIODE HZS9.11 DIODE HZS7.51 DIODE HZS7.55 DIODE HZS7.55 DIODE HZS7.55 DIODE HZS7.55	NB3 NB3 NB3 NB3 NB3 NB3 NB3 NB3 NB3 NB3		
C236	CERAMIC CHIP 4' BLECT CERAMIC CHIP 2' ELECT CERAMIC CHIP 0 CERAMIC CHIP 3' MYLAR CERAMIC CHIP 0 MYLAR CERAMIC CHIP 0 ELECT ELE	70PF .47MF 20PF 70MF .0056MF .0022MF .022MF .022MF .022MF .022MF .0047MF .1MF .0047MF .1MF .0MF .1MF .0MF .1MF .1MF .1MF .1MF .1MF .1MF .1MF .1	10% 20% 5% 20% 10% 10% 20% 20% 20% 20% 20% 20% 20% 20% 20% 2	50V 50V 50V 16V 50V 50V 50V 50V 50V 100V 50V 100V 50V 50V 50V 50V 50V 50V 50V 50V 50V	D201 D202 D205 D206 D1401 D1405 D1407 D1408 D1409 D1415 D1418 D1419 D1420 D1421 D1422 D1423 D1424 D1425	1-565-838-11 8-719-929-16 8-719-929-16 8-719-929-08 8-719-929-08 8-719-929-08 8-719-929-08 8-719-929-16 8-719-929-16 8-719-929-16 8-719-929-18 8-719-929-08 8-719-929-08 8-719-929-08 8-719-929-08 8-719-929-08 8-719-929-08 8-719-929-08 8-719-929-08	DIODE HZS9.11 DIODE HZS9.11 DIODE HZS9.11 DIODE HZS7.51 DIODE HZS7.51 DIODE HZS7.51 DIODE HZS7.51 DIODE HZS7.51 DIODE HZS9.11 DIODE HZS9.11 DIODE HZS9.11 DIODE HZS7.51	NB3 NB3 NB3 NB3 NB3 NB3 NB3 NB3 NB3 NB3		
C236	CBRAMIC CHIP 4' BLECT CERAMIC CHIP 2: BLECT 4' CERAMIC CHIP 0 CERAMIC CHIP 1 CERAMIC CHIP 3	70PF .47MF 20PF 70MF .0056MF .0026MF .022MF .022MF .022MF .022MF .0047MF .1MF .1MF .1MF .1MF .1MF .1MF .1MF .1	10% 20% 5% 20% 10% 10% 20% 20% 20% 20% 20% 20% 20% 20% 20% 2	50V 50V 50V 50V 50V 50V 50V 50V 50V 50V	D201 D202 D205 D206 D1401 D1404 D1405 D1407 D1408 D1409 D1410 D1415 D1418 D1419 D1420 D1421 D1422 D1423 D1424 D1425 D1426 D1501	1-565-838-11 8-719-929-16 8-719-929-18 8-719-929-08 8-719-929-08 8-719-929-08 8-719-929-16 8-719-929-16 8-719-929-16 8-719-929-16 8-719-929-16 8-719-929-08 8-719-929-08 8-719-929-08 8-719-929-08 8-719-929-08 8-719-929-08 8-719-929-08 8-719-929-08 8-719-929-08 8-719-929-08 8-719-929-08 8-719-929-08 8-719-929-08 8-719-929-08 8-719-929-08	DIODE HZS7.5N DIODE HZS9.11 DIODE HZS7.5N	NB3 NB3 NB3 NB3 NB3 NB3 NB3 NB3 NB3 NB3		
C236	CERAMIC CHIP 4' ELECT CERAMIC CHIP 0 ELECT 4' CERAMIC CHIP 0 MYLAR 0 ELECT 10 ELECT 10 ELECT 10 ELECT 22 ELECT 10 ELECT 20 ELECT 20 ELECT 10 ELECT 20 ELECT 10 ELE	70PF .47MF 20PF 70MF .0056MF .0026MF .022MF .022MF .022MF .022MF .0047MF .1MF 70MF 20MF 20MF 20MF 20MF 20MF 20MF .1MF .1MF .1MF .1MF .1MF .1MF .1MF .1	10% 20% 5% 20% 10% 10% 10% 20% 20% 20% 20% 20% 20% 20% 20% 20% 2	50V 50V 50V 50V 50V 50V 50V 50V	D201 D202 D205 D206 D1401 D1404 D1405 D1407 D1408 D1409 D1410 D1415 D1418 D1419 D1420 D1421 D1422 D1423 D1424 D1425 D1426 D1501	1-565-838-11 8-719-929-16 8-719-929-18 8-719-929-08 8-719-929-08 8-719-929-08 8-719-929-16 8-719-929-16 8-719-929-16 8-719-929-16 8-719-929-16 8-719-929-08 8-719-929-08 8-719-929-08 8-719-929-08 8-719-929-08 8-719-929-08 8-719-929-08 8-719-929-08 8-719-929-08 8-719-929-08 8-719-929-08 8-719-929-08 8-719-929-08 8-719-929-08	DIODE HZS7.5N DIODE HZS9.11 DIODE HZS7.5N	NB3 NB3 NB3 NB3 NB3 NB3 NB3 NB3 NB3 NB3		

REF.NC	G. PART NO.	DESCRIPTION	\			REMARK	REF.NO.	PART NO.	DESCRIPTION				RI
D150€	5 8-719-911-19 6 8-719-929-79 7 8-719-911-19 8-719-911-19	DIODE HZS36N DIODE ISSII) NB 4)				R246 R247 R248 R249 R250	1-216-067-00 1-216-075-00 1-216-067-00 1-216-075-00 1-216-067-00	METAL GLAZE	5.6K 12K 5.6K 12K 5.6K	5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
10140 10140	<pre>1 8-759-013-17 1 8-752-032-27 02 8-759-946-32 03 8-759-040-53</pre>	IC TDA6200 IC CXA1114P IC TEA2014A	.p				R1402 R1403 R1404 R1405	1-249-429-11	METAL GLAZE METAL GLAZE METAL GLAZE CARBON	82 68 47K 150 10K	5% 5% 5% 5%	1/10W 1/8W 1/10W 1/8W 1/4W	
10 15 0	01 8-759-942-16	IC TEA2031A		C			R1408 R1409	1-216-113-00 1-216-089-00 1-216-041-00 1-216-089-00 1-216-041-00	METAL GLAZE METAL GLAZE	470K 47K 470 47K 470	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
9201 9202 91401 91402 91403	8-729-271-22 8-729-271-22 8-729-216-22 8-729-271-22 8-729-119-78 8-729-173-38	TRANSISTOR 2 TRANSISTOR 2 TRANSISTOR 2 TRANSISTOR 2 TRANSISTOR 2	SC2712- SC2712- SA1162- SC2712- SC2785-	-G -G -G -HFE			R1412 R1413 R1414 R1415 R1416	1-216-089-00 1-216-113-00 1-216-089-00 1-216-083-00 1-216-083-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	47K 470K 47K 27K 27K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
	<res< td=""><td>SISTOR></td><td></td><td></td><td></td><td></td><td>R1417 R1418 R1422 R1423</td><td>1-216-023-00 1-247-738-11 1-216-025-00 1-216-089-00 1-216-089-00</td><td>METAL GLAZE CARBON METAL GLAZE METAL GLAZE</td><td>82 82 100 47K</td><td>5% 5% 5% 5%</td><td>1/10W 1/2W F 1/10W 1/10W</td><td>7</td></res<>	SISTOR>					R1417 R1418 R1422 R1423	1-216-023-00 1-247-738-11 1-216-025-00 1-216-089-00 1-216-089-00	METAL GLAZE CARBON METAL GLAZE METAL GLAZE	82 82 100 47K	5% 5% 5% 5%	1/10W 1/2W F 1/10W 1/10W	7
R201 R202 R203 R204 R205	1-216-079-00 1-216-206-00 1-216-075-00 1-216-085-00 1-216-085-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	18K 2.2K 12K 33K 33K	5% 5% 5%	1/10W 1/8W 1/10W 1/10W 1/10W	,	R1424 R1425 R1426 R1427	1-216-049-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	47K 1K 100 10 470K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
R206 R207 R208 R209 R210	1-216-061-00 1-216-061-00 1-216-077-00 1-216-081-00 1-216-077-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	3.3K 3.3K 15K 22K 15K	5% 5% 5% 5%	1/1UW		R1430 R1431 R1432	1-216-170-00 1-216-041-00 1-216-041-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE		55 % % % % % % % % % % % % % % % % % %	1/10W 1/10W 1/10W 1/10W	
R211 R212 R213 R214	1-216-033-00	METAL GLAZE METAL GLAZE METAL GLAZE	22K 15K 220	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R1434 R1434 R1437 R1440	1-216-033-00 1-249-393-11 1-249-429-11 1-216-045-00	METAL GLAZE CARBON CARBON METAL GLAZE	220 10 10K 680	5% 5% 5% 5%	1/10W 1/4W F 1/4W 1/10W	ì
R215 R216 R217 R218	1-216-077-00 1-216-033-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	22K 22K 15K 220 10K 2.2K		1/100		R1442	1-216-089-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	680 47K 47K 220	5% 5%	1/10W 1/10W 1/10W	
R219 R220 R221 R222	1-216-073-00 1-216-057-00 1-216-041-00 1-216-041-00	METAL GLAZE METAL GLAZE	470 470	5% 5%	1/10W 1/10W		R1448	1-216-033-00 1-216-095-00 1-216-033-00 1-216-033-00 1-216-025-00	METAL GLAZE	82K 220 220 100	5% 5%	1/10W 1/10W 1/10W 1/10W	
R223 R224 R225 R226 R227	1-216-049-00 1-216-049-00 1-216-049-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	1 K 1 K 1 K	5% 5% 5% 5%	1/10W 1/10W 1/10W		R1453 R1454 R1455	1-216-049-00 1-216-049-00 1-216-180-00 1-216-180-00 1-216-025-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	1 K 1 K 1 8 O 1 8 O 1 0 O	5% 5% 5% 5%	1/10W 1/10W 1/8W 1/8W 1/10W	
R228 R229 R230	1-216-033-00 1-216-033-00 1-216-075-00 1-216-079-00 1-216-073-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	220 220 12K 18K	5% 5% 5%	1/10W 1/10W 1/10W 1/10W		R1460 R1461 R1462	1-216-025-00 1-216-065-00 1-216-190-00 1-216-057-00 1-216-055-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	100 4.7K 470 2.2K 1.8K	5% 5% 5% 5%	1/10W 1/10W 1/8W 1/10W 1/10W	
R232 R233 R234 R240	1-216-073-00 1-216-057-00 1-216-057-00 1-216-033-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	10K 2.2K 2.2K 220	5%% 5%% 5%%	1/10W 1/10W 1/10W 1/10W 1/10W		R1464 R1465 R1466	1-216-059-00 1-216-023-00 1-216-033-00 1-216-025-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	2.7K 82 220 100	5% 5% 5%	1/10W 1/10W 1/10W 1/10W	
R241 R242 R243 R244 R245	1-216-067-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	56K 56K 12K 5.6K 12K	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	 1 1 1 1 1 1 1 1	R1469 R1470 R1471	1-216-025-00 1-216-025-00 1-216-025-00 1-216-023-00 1-216-023-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	100 100 100 82 82	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	

J1 J2 IFG

REF.NO. PART NG.	DESCRIPTION		REMARK	REF.NO	. PART No.	DESCRIPTION			REMARK
R1473 1-216-023-00 R1474 1-216-113-00 R1476 1-216-089-00) METAL GLAZE 470F	5% 1/	10M		1 412 240 !!				
R1476 1-216-089-00 R1477 1-216-089-00 R1478 1-216-113-00	METAL GLAZE 47K	5% 1/	10m 10m	1	**************************************				*******
R1480 1-216-190-00 R1482 1-216-178-00 R1483 1-216-178-00	METAL GLAZE 150 METAL GLAZE 150	5% 1/ 5% 1/	8W 8W		*A-1654-003-A *1:565:488:11	CONNECTOR. B	GARD TO BOA	RD 12P	
R1484 1-216-073-00 R1485 1-216-073-00	METAL GLAZE 10K	5% 1/	10W 10W	1 1 1	e C'AP	ACT TOR>			
R1486 1-216-073-00 R1487 1-216-065-00 R1488 1-216-065-00 R1489 1-216-065-00 R1501 1-216-081-00	METAL GLAZE	5% 1/ 5% 1/ 5% 1/	10W 10W 10W 10W 10W	C1 C2 C3 C4 C5	1-164-232-11 1-164-232-11 1-164-232-11 1-164-232-11 1-164-232-11	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	0.01MF 0.01MF 0.01MF		50V 50V 50V 50V 50V
R1502 I-216-083-00 R1503 I-216-113-00 R1504 I-216-085-00 R1505 I-216-081-00 R1506 I-216-113-00	METAL GLAZE 470K METAL GLAZE 33K METAL GLAZE 22K	5% 1/ 5% 1/ 5% 1/	10W 10W	C6 C7 C8 C9 C10	1 164-232:11 1-124-791:11 1-123-875:11 1-130-471-00 1:163-121:00	CERAMIC CHIP ELECT ELECT MYLAR CERAMIC CHIP	IMF IOMF 0.001MF	20% 20% 10% 5%	50V 50V 50V 50V 50V
R1509 1 216-105-00 R1510 1-216-067-00 R1511 1-216-049-00 R1512 1-216-073-00 R1513 1-216-091-00	METAL GLAZE 5.6K METAL GLAZE 1K METAL GLAZE 10K	5% I/ 5% 1/ 5% 1/	10W 10W 10W 10W 110W	C11 C12 C13 C14 C15	1-163 119-00 1-136-298-00 1-124-477-11 1-124-477-11	CERAMIC CHIP FILM BLECT BLECT FIECT	120PF 0.0033MF 47MF 47MF 47MF	5% 2% 20% 20% 20%	50V 100V 16V 16V 16V
R1514 1-216-049-00 R1515 1 216 117-00 R1516 1-216-079-03 R1517 1-216-033-00 R1519 1-216-101-00	METAL GLAZE 680K METAL GLAZE 18K METAL GLAZE 220	5% 1/ 5% 1/ 5% 1/	10W 10W 10W 10W	C16 C17 C18 C19 C20	1 124 477 11 1 123 875 11 1 106 367 00 1 106 367 00 1 126 233 11	ELECT ELECT MYLAE MYLAR ELECT	47MF 10MF 0.01MF 0.01MF 22MF	20% 20% 10% 10% 20%	16V 50V 400V 400V 50V
R1520 I-216-113-00 R1521 I-216-214-00 R1556 I-216-067-00	METAL GLAZE 4.7K METAL GLAZE 5.6K	5% 1/3 5% 1/	10W	C21 C22 C23 C24 C25	1-126-233-11 1-106-220-00 1-106-228-00 1-124-963-11 1-106-375-12	MYLAR Elect	22MF 0.1MF 0.22MF 33MF 0.022MF	20% 10% 10% 20% 10%	50V 100V 100V 16V 250V
<pre><va 1-238-023-11<="" pre="" rv1501=""></va></pre>	RIABLE RESISTOR> RES, ADJ, CARBON 4	7 0K		C26	1-106-383-00 1-124-791-11	MYLAR Elect	0.047MF 1MF	10% 20%	100V 50V
RV1502 1-228-994-00 RV1503 1-238-017-11 RV1504 1-238-012-11 RV1505 1-238-023-11	RES, ADJ, CARBON 1 RES. ADJ. CARBON 2	0K 2K K		C28 C29 C30	1-163-103-00 1-124-791-11 1-124-791-11	CERAMIC CHIP ELECT	27PF 1MF 1MF	5% 20% 20%	50V 50V 50V
RV1506 1-238-017-11 RV1507 1-238-009-11	RES, ADJ, CARBON 2	2K 20 0K		C31 C32 C33 C34	1-106-367-00 1-130-479-00 1-163-081-00 1-106-228-00	MYLAR CERAMIC CHIP	0.01MF 0.0047MF 0.22MF 0.22MF	10% 5% 10%	400V 50V 25V 100V
	RES, ADJ. CARBON 4		*******	C35	1-123-875-11 1-163-119-00	CERAMIC CHIP	10 M F	20% 5%	50V 50V
*1-633-411-11	J2 BOARD			C37 C38	1-124-477-11 1-124-477-11	ELECT	47MF 47MF	20% 20%	16V 16V
	PLUG, CONNECTOR 4P	PUT/OUTPUT		1 4 1 3	<f1l< td=""><td>rer></td><td></td><td></td><td></td></f1l<>	rer>			
	PLUG, CONNECTOR 2P PLUG, CONNECTOR 4P			CDA1 CDA2 SFT1 SFT2	1-404-751-11 1-404-750-11 1-527-840-00 1-527-839-00	DISCRIMINATOR FILTER, CERAN	R. CERAMIC MIC		
	PACITOR	als.		3112			7,1		
C1751 1-101-005-00 C1752 1-101-005-00 C1755 1-102-114-00 C1756 1-102-114-00	CERAMIC 0.022 CERAMIC 470PF		50V 50V 50V 50V	D3	8-719-400-18		‹		
		10%	301		<10>				
<003 L1751 1-412-240-11)		1C1 1C2	8-759-003-90 8-759-003-90				

The components identified by hading and mark $\hat{\Delta}$ are critical for safety.
Replace only with part number specified.

	REF NO.	PART NO.	DESCRIPTION		REMARK
	IC3 IC4	8 · 759 - 030 - 48 8 - 759 - 946 - 99	IC TDA6600-2 IC TDA2595-V	7	
		<001	L>		
	L1 L2 L3 L4 L5	1-408-410-00 1-408-410-00 1-410-064-11 1-408-421-00 1-408-421-00	INDUCTOR INDUCTOR INDUCTOR INDUCTOR INDUCTOR	12UH 12UH 2.7MMH 100UH 100UH	
		<tra< th=""><th>NSISTOR></th><th></th><th></th></tra<>	NSISTOR>		
	Q2 Q3 Q4	8-729-901-00 8-729-216-22 8-729-901-00	TRANSISTOR D' TRANSISTOR 2: TRANSISTOR D'	SA1162-G	
		RES	ISTOR		
)	JR8 JR10 R1 R2 R3	1-216-296-00 1-216-296-00 1-216-045-00 1-216-043-00 1-216-043-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 5% 0 5% 680 5% 560 5% 560 5%	1/8W 1/8W 1/10W 1/10W 1/10W
	R5 R6 R7 R9 R10	1-216-045-00 1-216-043-00 1-216-043-00 1-216-073-00 1-216-077-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	680 5% 560 5% 560 5% 10K 5% 15K 5%	1/10W 1/10W 1/10W 1/10W 1/10W
	R11 R12 R15 R16 R17	1-216-097-00 1-216-097-00 1-216-059-00 1-216-097-00 1-216-097-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	100K 5% 100K 5% 2.7K 5% 100K 5% 100K 5%	1/10W 1/10W 1/10W 1/10W 1/10W
	R18 R19 R20 R22 R24	1-216-063-00 1-216-097-00 1-216-075-00 1-216-099-00 1-216-089-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	3.9K 5% 100K 5% 12K 5% 12OK 5% 47K 5%	1/10W 1/10W 1/10W 1/10W 1/10W
	R25	1-216-077-00	METAL GLAZE	15K 5%	1/10W
		< VAR	TABLE RESISTOR	Þ	
1	RV1 RV2	I-238-016-11 I-238-019-11	RES, ADJ. CAR RES. ADJ. CAR		
	*****	*********	*********	********	**********
			CELLANEOUS		
	A .	1-236-510-11 1-426-372-11 1-451-311-21 1-452-032-00 1-452-094-00	- CUIL. DEMAGNI	DKE (Y25FXA) 10MM ø	
	∆ .	1-503-642-41 1-544-146-11 1-544-147-11 1-575-487-11	SPEAKER (KV-C SPEAKER (KV-C SPEAKER (KV-C CORD, POWER (V	2531D ONLY) 2531D ONLY)	ilter)* **********

V901 A.8-733-224-05 PICTURE TUBE (A59JWC60X)

IFG

ACCESSORIES AND PACKING MATERIALS

PART NO.	DESCRIPTION	REMARK
1-465-363-11 4-200-241-11 4-200-262-11 *4-200-236-01 *4-200-237-01 *4-200-238-01	COMMANDER, REMOTE (RM-689) MANUAL, INSTRUCTION MANUAL, INSTRUCTION (KV-C) CUSHION (UPPER) (ASSY) INDIVIDUAL CARTON CUSHION, LOWER	(KV-C2521D ONLY) 2531D ONLY)
*4-381-155-01	BAG. PROTECTION	